



**PRONAR Sp. z o.o.**

17-210 NAREW, UL. MICKIEWICZA 101A, PODLASKIE PROVINCE

|       |                   |                   |
|-------|-------------------|-------------------|
| tel.: | +48 085 681 63 29 | +48 085 681 64 29 |
|       | +48 085 681 63 81 | +48 085 681 63 82 |
| fax:  | +48 085 681 63 83 | +48 085 682 71 10 |


[www.pronar.pl](http://www.pronar.pl)

# OPERATOR`S MANUAL

## MULTI-FUNCTION ARM

## PRONAR WWP500UH

TRANSLATION OF THE ORIGINAL COPY OF THE MANUAL



EDITION 1B-09-2017

PUBLICATION NO. 554N-00000000-UM

EN



# MULTI-FUNCTION ARM

# PRONAR WWP500UH

## MACHINE IDENTIFICATION

SYMBOL /TYPE:

SERIAL NUMBER:

|  |  |  |  |  |  |
|--|--|--|--|--|--|
|  |  |  |  |  |  |
|--|--|--|--|--|--|

# INTRODUCTION

Information contained herein is current at date of publication. As a result of improvements, some numerical values and illustrations contained in this publication may not correspond to the factual specification of the machine supplied to the user. The manufacturer reserves the right to introduce design changes in machines produced that facilitate operation and improve the quality of their work, without making minor amendments to this Operator's Manual.

This Operator's Manual is an integral part of the machine's documentation. Before using the machine, the user must carefully read this Operator's Manual and observe all recommendations. This guarantees safe operation and ensures failure-free work of the machine. The machine is designed to meet obligatory standards, documents and legal regulations currently in force.

The manual describes the basic safety rules and operation of PRONAR WWP500UH multifunction arm. If the information stated in the Operator's Manual needs clarification then the user should refer for assistance to the sale point where the machine was purchased or to the Manufacturer.

## MANUFACTURER'S ADDRESS:

*PRONAR Sp. z o.o.  
ul. Mickiewicza 101A  
17-210 Narew*

## CONTACT TELEPHONES

*+48 085 681 63 29*

*+48 085 681 64 29*

*+48 085 681 63 81*

*+48 085 681 63 82*

## SYMBOLS APPEARING IN THIS OPERATOR'S MANUAL

Information, descriptions of danger and precautions and also recommendations and prohibitions associated with user safety instructions are marked:



and also preceded by the word "**DANGER**". Failure to observe the instructions may endanger the machine operator's or other person's health or life.

Particularly important information and instructions, the observance of which is essential, are distinguished in the text by the sign:



and also preceded by the word "**ATTENTION**". Failure to observe the instructions may lead to damage to the machine as a result of improper operation, adjustment or use.

In order to focus the user's attention on the need to perform maintenance, the relevant section of the Operator's Manual is marked with the pictogram:



Additional tips and advice for machine operation are marked with the sign:



and also preceded by the word "**TIP**".

## DIRECTIONS USED IN THIS OPERATOR'S MANUAL

Left side – side to the left hand of the operator facing in the direction of machine's forward travel.

Right side – side to the right hand of the operator facing in the direction of machine's forward travel.





**PRONAR Sp. z o.o.**

ul. Mickiewicza 101 A

17-210 Narew, Polska

tel./fax (+48 85) 681 63 29, 681 63 81, 681 63 82,  
681 63 84, 681 64 29

fax (+48 85) 681 63 83

http://www.pronar.pl

e-mail: pronar@pronar.pl

## EC DECLARATION OF CONFORMITY OF THE MACHINERY

PRONAR Sp. z o.o. declares with full responsibility, that the machine:

| Description and identification of the machinery |   |                 |
|---|---|-----------------|
| Generic denomination and function:              | <b>Multifunction arm</b>  |                 |
| Type:   | <b>WWP500U</b>  | <b>WWP500UH</b> |
| Model:  | —   | —               |
| Serial number:                                  |   |                 |
| Commercial name:                                | <b>Multifunction arm PRONAR WWP500U</b><br><b>Multifunction arm PRONAR WWP500UH</b> |                 |

to which this declaration relates, fulfills all the relevant provisions of the Directive **2006/42/EC** of The European Parliament and of The Council of 17 May 2006 on machinery, and amending Directive 95/16/EC (Official Journal of the EU, L 157/24 of 09.06.2006).

The person authorized to compile the technical file is the Head of Research and Development Department at PRONAR Sp. z o.o., 17-210 Narew, ul. Mickiewicza 101A, Poland.

This declaration relates exclusively to the machinery in the state in which it was placed on the market, and excludes components which are added and/or operations carried out subsequently by the final user.

Narew, the 18 PAŻ. 2012

*Place and date*

Z-CA DYREKTORA  
d/s technicznych  
członek zarządu  
*Roman Omelianiuk*

*Full name of the empowered person  
position, signature*





# TABLE OF CONTENTS

|          |                                     |            |
|----------|-------------------------------------|------------|
| <b>1</b> | <b>BASIC INFORMATION</b>            | <b>1.1</b> |
| 1.1      | IDENTIFICATION                      | 1.2        |
| 1.2      | PROPER USE                          | 1.3        |
| 1.3      | EQUIPMENT                           | 1.6        |
| 1.4      | WARRANTY TERMS                      | 1.6        |
| 1.5      | TRANSPORT                           | 1.7        |
| 1.6      | ENVIRONMENTAL HAZARDS               | 1.10       |
| 1.7      | WITHDRAWAL FROM USE                 | 1.10       |
| <b>2</b> | <b>SAFETY ADVICE</b>                | <b>2.1</b> |
| 2.1      | BASIC SAFETY RULES                  | 2.2        |
| 2.1.1    | USE OF MACHINE                      | 2.2        |
| 2.1.2    | HITCHING AND UNHITCHING THE MACHINE | 2.3        |
| 2.1.3    | HYDRAULIC SYSTEM                    | 2.3        |
| 2.1.4    | TRANSPORTING THE MACHINE            | 2.4        |
| 2.1.5    | MAINTENANCE                         | 2.5        |
| 2.1.6    | OPERATING THE MULTIFUNCTION ARM     | 2.6        |
| 2.1.7    | OPERATION OF                        | 2.7        |
| 2.2      | RESIDUAL RISK                       | 2.9        |
| 2.3      | INFORMATION AND WARNING DECALS      | 2.10       |
| <b>3</b> | <b>DESIGN AND OPERATION</b>         | <b>3.1</b> |
| 3.1      | TECHNICAL SPECIFICATION             | 3.2        |
| 3.2      | GENERAL DESIGN AND OPERATION        | 3.3        |

|          |   |            |
|----------|---|------------|
| <b>4</b> | <b>CORRECT USE</b>  | <b>4.1</b> |
| 4.1      | PREPARING FOR WORK  | 4.2        |
| 4.2      | TECHNICAL INSPECTION  | 4.4        |
| 4.3      | HITCHING TO UNIVERSAL CARRYING VEHICLE                                      | 4.5        |
| 4.3.1    | HITCHING THE MULTIFUNCTION ARM TO THE CARRYING VEHICLE'S LINKAGE            | 4.5        |
| 4.3.2    | CONNECTING THE CARRYING VEHICLE'S ELECTRICAL SYSTEM                         | 4.7        |
| 4.4      | BALLASTING THE CARRYING VEHICLE   | 4.10       |
| 4.5      | START AND OPERATION OF THE MULTIFUNCTION ARM BY MEANS OF THE CONTROL SYSTEM | 4.11       |
| 4.6      | ATTACHING THE WORKING HEAD  | 4.15       |
| 4.7      | TRANSPORTING THE MACHINE  | 4.18       |
| 4.8      | SETTING THE MULTIFUNCTION ARM IN WORKING POSITION AND OPERATION             | 4.20       |
| <b>5</b> | <b>MAINTENANCE</b>  | <b>5.1</b> |
| 5.1      | HYDRAULIC SYSTEM MAINTENANCE  | 5.2        |
| 5.1.1    | OIL TANK AND OIL FILTERS  | 5.3        |
| 5.1.2    | MULTIPLIER GEAR BOX WITH THE HYDRAULIC OIL PUMP ASSEMBLY                    | 5.7        |
| 5.1.3    | ELECTROHYDRAULIC SELECTIVE CONTROL VALVES                                   | 5.8        |
| 5.2      | LUBRICATION   | 5.9        |
| 5.3      | TIGHTENING BOLT CONNECTIONS   | 5.11       |
| 5.4      | STORAGE   | 5.13       |
| 5.5      | TROUBLESHOOTING   | 5.14       |


*SECTION*

**1**

---

**BASIC INFORMATION**

# 1.1 IDENTIFICATION



**FIGURE 1.1** Location of the data plate.

PRONAR WWP500UH multifunction arm is marked with the data plate located on the multifunction arm mast. When buying the machine check that the serial numbers on the machine agree with the number written in the *WARRANTY BOOK*, in the sales documents and in the *OPERATOR'S MANUAL*.



Using it as intended involves all actions connected with the safe and proper operation and maintenance of the machine. Due to the above, the user is obliged to:

- carefully read the *OPERATOR'S MANUAL* and comply with its recommendations,
- understand the machine's operating principle and how to operate it safely and correctly,
- adhere to the established maintenance and adjustment plans,
- comply with general safety regulations while working,
- prevent accidents,
- comply with the road traffic regulations and transport regulations in force in the given country, in which the machine is used,
- carefully read the universal carrying vehicle's operator's manual and comply with its recommendations.

The multifunction arm may only be used by persons, who:


- are familiar with the contents of this publication and with the contents of the carrying vehicle's operator's manual,
- have been trained in the multifunction arm safe operation,
- have the required authorisation to drive carrying vehicles and are familiar with the road traffic regulations and transport regulations.

**TABLE 1.1 Requirements for carrying vehicle.**

| CONTENTS                                | UNIT | REQUIREMENTS  |
|---|------|---|
| <b>Carrying vehicle's linkage</b>       |      | DIN 76060 type A, DIN 76060 type B or SETRA linkage |
| <b>Front power take-off shaft (PTO)</b> |      |   |
| Type                                    | -    | Type 1 (1 3/4") acc. to ISO 730-1                   |
| Rotation speed                          | rpm  | 1000  |
| Number of splines on PTO shaft          | pc.  | 6   |
| Rotation direction                      | -    | Left (anticlockwise, looking at the shaft front)    |

**TABLE 1.2** Allowable position of the front power take-off shaft (PTO) of the carrying vehicle in relation to the multifunction arm linkage.

| DIMENSION<br>(FIGURE 1.2) | UNIT | DIN 76060 TYPE A<br>and B<br>Position I | DIN 76060 TYPE A<br>and B<br>position II | SETRA   |
|---------------------------|------|---|--|---------|
| A                         | mm   | 100-165                                 | 100-165                                  | 100-165 |
| B                         | mm   | 60-170                                  | 120-230                                  | -       |
| C                         | mm   | -                                       | -  | 390-500 |
| D                         | mm   | 110-180                                 | 110-180                                  | 110-180 |
| E                         | mm   | 570                                     | 510                                      | 240     |



**FIGURE 1.2** Position of the front power take-off shaft (PTO) of the carrying vehicle in relation to the multifunction arm linkage.

## 1.3 EQUIPMENT

**TABLE 1.3** Equipment of PRONAR WWP500UH multifunction arm

| EQUIPMENT                        | STANDARD | OPTION |
|----------------------------------|----------|--------|
| Operator's Manual                | •        |        |
| Warranty book                    | •        |        |
| Fixing elements DIN A            | •        |        |
| Fixing elements DIN B            |          | •      |
| Fixing elements SETRA            |          | •      |
| Working head connection TYPE 80P | •        |        |
| Working head connection TYPE 60P |          | •      |
| Adapter P0G01                    |          | •      |
| Jockey wheel                     |          | •      |
| Power supply wiring harness      | •        |        |
| Stand                            | •        |        |

## 1.4 WARRANTY TERMS

PRONAR Sp. z o.o. Narew guarantees the reliable operation of the machine when it is used according to its intended purpose as described in the *OPERATOR'S MANUAL*. Defects discovered during the warranty period will be removed by the Warranty Service. The repair period is specified in the *WARRANTY BOOK*.

The warranty does not cover those parts and sub-assemblies of the machine which are subject to wear in normal usage conditions, regardless of the warranty period.

The warranty service only applies to such cases as: mechanical damage which is not the user's fault, factory defects of parts, etc.

In the event of damage arising from:

- mechanical damage which is the user's fault, road accidents,



- inappropriate use, adjustment or maintenance, use of the machine for purposes other than those for which it is intended,
- use of damaged machine,
- repairs carried out by unauthorised persons, repairs carried out improperly,
- making unauthorised alterations to machine design,

the user will lose the right to warranty service.



### TIP

**Demand that the seller carefully and precisely fills out the WARRANTY BOOK and guarantee repair coupons. A missing date of purchase or sale point stamp may make the user ineligible for any warranty repair or refund.**

The user is obliged to report immediately on noticing any wear in the paint coating or traces of corrosion, and to have the faults rectified whether they are covered by the warranty or not. For detailed Terms & Conditions of Warranty, please refer to the WARRANTY BOOK attached to each newly purchased machine.

Modification of the multifunction arm without the written consent of the Manufacturer is prohibited. In particular, do NOT weld, drill holes in, cut or heat the main structural elements of the machine, which have a direct impact on the machine operation safety.

## 1.5 TRANSPORT

The multifunction arm is ready for sale completely assembled and does not require packing. Packing is only required for the machine's technical documentation and any extra fittings.



### ATTENTION

**Before transporting independently, the universal carrying vehicle driver must carefully read this Operator's Manual and observe its recommendations. When being transported on a motor vehicle the multifunction arm must be mounted on the vehicle's platform in accordance with the transport safety requirements. The driver of the vehicle should take particular care while driving. This is due to the vehicle's centre of gravity shifting upwards when loaded with the machine.**

Delivery is either by transport on a vehicle or independently. Transport of the multifunction arm hitched to an universal carrying vehicle is allowed provided that the vehicle driver is familiar with the Operator's Manual of the multifunction arm, in particular, with information

concerning safety and principles of hitching and transport on public roads. Do NOT drive the universal carrying vehicle with the multifunction arm hitched when visibility is limited.

When loading and unloading the multifunction arm, comply with the general principles of workplace health and safety for reloading work. Persons operating reloading equipment must have the qualifications required to operate these machines.




### ATTENTION

Do NOT secure lifting slings or any types of securing elements to hydraulic cylinders.



### TIP

During loading, the multifunction arm should be placed on the stand in transport position, without the working head. (FIGURE 1.3).



**FIGURE 1.3 Multifunction arm stand.**


*(1)- stand; (2)- multifunction arm*

During transport and storage, the multifunction arm should be mounted on special stand (FIGURE 1.3). The stand is used for loading the multifunction arm with the aid of a forklift truck to the platform of the transport vehicle.

The multifunction arm should be attached firmly to the platform of the vehicle using straps or chains fitted with a tightening mechanism. The fastening equipment used must have a valid safety certificate. Exercise particular caution when lifting the stand with the machine. During the loading work particular care should be taken not to damage paint coating.

**ATTENTION**

Nobody may be in the manoeuvring zone during transferring multifunction arm to other means of transport.



**FIGURE 1.4** Location of centre of gravity of the multifunction arm in transport position (without hydraulic oil in the tank).

**ATTENTION**

Depending on the machine version, location of centre of gravity varies in the range of  $\pm 50$ .

## 1.6 ENVIRONMENTAL HAZARDS

A hydraulic oil leak constitutes a direct threat to the natural environment owing to its limited biodegradability. While carrying out maintenance and repair work which involves the risk of an oil leak, this work should take place on an oil resistant floor or surface. In the event of oil leaking into the environment, first of all contain the source of the leak, and then collect the leaked oil using available means. Remaining oil should be collected using sorbents, or by mixing the oil with sand, sawdust or other absorbent materials. The oil contaminations, once gathered up, should be kept in a sealed, marked, hydrocarbon resistant container, and then passed on to the appropriate oil waste recycling centre. The container should be kept away from heat sources, flammable materials and food.

Oil which has been used up or is unsuitable for further use owing to loss of its properties should be stored in its original packaging in the conditions described above.

## 1.7 WITHDRAWAL FROM USE

In the event of decision by the user to withdraw the machine from use, comply with the regulations in force in the given country concerning withdrawal from use and recycling of machines withdrawn from use.

Before proceeding to dismantle equipment, oil shall be completely removed from hydraulic system and transmission. Locations of drain plugs and method for draining oil are described in Section 5.

When spare parts are changed, worn out or damaged parts should be taken to a collection point for recyclable raw materials. Used oil and also rubber and plastic elements should be taken to the appropriate facilities dealing with the recycling of this type of waste.



### **ATTENTION**

**During dismantling, personal protection equipment shall be used i.e. protective clothing, boots, gloves and protective goggles etc.**

**Avoid contact of skin with oil. Do not allow used oil to spill.**

**SECTION**

**2**

---

**SAFETY ADVICE**

## 2.1 BASIC SAFETY RULES

### 2.1.1 USE OF MACHINE

- Before using the machine, the user must carefully read this Operator's Manual and the *WARRANTY BOOK*. When operating the machine, the operator must comply with all recommendations contained in the Operator's Manual.
- The multifunction arm may only be used and operated by persons qualified to drive universal carrying vehicle and trained in the use of the machine. The multifunction arm can be operated by a single person only.
- If the information contained in the Operator's Manual is difficult to understand, contact the seller who runs the authorised technical service on behalf of the Manufacturer, or contact the Manufacturer directly.
- Careless and incorrect use and operation of the machine, and non-compliance with the recommendations given in this operator's manual is dangerous to your health.
- Be aware of the residual risk. Use caution when operating this multifunction arm and apply all relevant safety principles.
- The machine must never be used by persons who are not authorised to drive universal carrying vehicle, including children and people under the influence of alcohol or other drugs.
- Non-compliance with the safety rules of this Operator's Manual can be dangerous to the health and life of the operator and others.
- The machine must not be used for purposes other than those for which it is intended. Anyone who uses the multifunction arm other than the way intended takes full responsibility for himself for any consequences of this use. Use of the machine for purposes other than those for which it is intended by the Manufacturer may invalidate the guarantee.
- The multifunction arm may only be used when all the safety guards and other protective elements are technically sound and correctly positioned. In the event of loss or destruction of the safety guards, they must be replaced with new ones.
- Do NOT operate the multifunction arm with the carrying vehicle without the driver's cab. The carrying vehicle should be equipped with the cab protecting the operator

against possible hazards. The operator should also use personal protective equipment such as protective clothing, safety goggles, safety helmet to reduce the risk of injuries.

- In order to limit occupational risks associated with exposure to noise during multifunction arm operation use individual protection (hearing protectors). In order to reduce the level of noise during work, the operator cab windows and door should be closed.

### **2.1.2 HITCHING AND UNHITCHING THE MACHINE**

- Do NOT hitch the multifunction arm to universal carrying vehicle if the linkage systems of the machine and the vehicle are not compatible.
- Only the front linkage of the carrying vehicle should be used for hitching the machine. After hitching the machine, check the safeguards. After coupling the machine, check the safeguards. Carefully read the Operator's Manual of the carrying vehicle.
- Use only genuine safeguards to hitch the machine to the carrying vehicle.
- The carrying vehicle to which the multifunction arm will be hitched must be technically reliable and must fulfil the requirements of the machine Manufacturer.
- Be especially careful when hitching the machine.
- When hitching, there must be nobody between the multifunction arm and the carrying vehicle.
- Unhitching the multifunction arm from the carrying vehicle is forbidden when the working head is connected with the multifunction arm. Exercise caution when unhitching the machine.
- Hitching and unhitching may only take place with the machine and carrying vehicle switched off.
- Multifunction arm unhitched from the carrying vehicle must be mounted on the stand and supported on stable and level surface.

### **2.1.3 HYDRAULIC SYSTEM**

- The hydraulic system is under high pressure when operating.

- Regularly check the technical condition of the connections and the hydraulic conduits. There must be no oil leaks.
- In the event of the hydraulic system malfunction, discontinue using the machine until the malfunction is corrected.
- When connecting the hydraulic conduits to the working head, make sure that the hydraulic system of the multifunction arm is not under pressure. If necessary, reduce residual pressure in the system.
- In the event of injuries being caused by pressurised hydraulic oil, contact a doctor immediately. Hydraulic oil may penetrate the skin and cause infections. In the event of contact of oil with eyes, rinse eyes with a large quantity of water and in the event of the occurrence of irritation consult a doctor. In the event of contact of oil with skin wash the area of contact with water and soap. Do NOT apply organic solvents (petrol, kerosene).
- Use the hydraulic oil recommended by the Manufacturer. Never mix two types of oil.
- After changing the hydraulic oil, the used oil should be properly disposed of. Used oil or oil which has lost its properties should be stored in original containers or replacement containers resistant to action of hydrocarbons. Replacement containers must be clearly marked and appropriately stored.
- Do not store hydraulic oil in packaging designed for storing food or foodstuffs.
- Rubber hydraulic conduits must be replaced every 4 years regardless of their technical condition.
- Repair and replacement of hydraulic system elements should be entrusted to the appropriately qualified persons.

#### **2.1.4 TRANSPORTING THE MACHINE**

- When driving on public roads, comply with the road traffic regulations in force in the country in which the machine is used.
- Do not exceed the permitted speed arising from road conditions and design limitations. Adjust travelling speed to the prevailing road conditions and other limitations specified in the road traffic regulations.
- Before beginning travel, the multifunction arm must be folded to transport position.



- Do NOT leave the working head raised and unsecured while the universal carrying vehicle is parked. When parked, the working head should be lowered to the ground or mounted on the working head hitch.
- Do not transport the multifunction arm set in the working position.
- The multifunction arm may not be used or transported in conditions of limited visibility.
- Do NOT ride on the machine or transport any materials on it.
- Before using the machine always check its technical condition, especially in terms of safety. In particular, check the technical condition of the linkage and connection elements of the hydraulic system.
- Reckless driving and excessive speed may cause accidents.

### **2.1.5 MAINTENANCE**

- During the warranty period, any repairs may only be carried out by warranty service authorised by the Manufacturer. It is recommended that necessary repairs to machine should be undertaken by specialised workshops.
- In the event of any fault or damage, do not use the multifunction arm until the fault has been corrected.
- During work, use the proper, close-fitting protective clothing, gloves and appropriate tools. When working on hydraulic systems it is recommended to use oil resistant gloves and protective goggles.
- Any modification to the multifunction arm frees the manufacturer from any responsibility for damage or detriment to health, which may arise as a result.
- Before undertaking any work on the multifunction arm turn off the carrying vehicle engine and wait until all rotating parts come to a stop.
- Regularly check the technical condition of the safety devices and correct tightening of bolt connections.
- Regularly perform service inspections of machine as recommended by the Manufacturer.
- Do NOT perform maintenance or repair work under raised and unsupported machine.

- Before beginning repair works on hydraulic systems, reduce oil pressure.
- Servicing and repair work should be carried out in line with the general principles of workplace health and safety. In the event of injury, the wound must be immediately cleaned and disinfected. In the event of more serious injuries, seek a doctor's advice.
- Repair, maintenance and cleaning work should be carried out with the carrying vehicle engine turned off and the ignition key removed. Immobilise the carrying vehicle with parking brake. Ensure that unauthorised persons do not have access to the carrying vehicle cab.
- Should it be necessary to change individual parts, use only original parts. Non-adherence to these requirements may put the user and other people's health and life at risk, and also damage the machine and invalidate the warranty.
- Regularly check technical condition and mounting of all guards and protective elements.
- In the event of work requiring the multifunction arm to be raised, use properly certified hydraulic or mechanical lift jacks for this purpose. After lifting the machine, stable and durable supports must also be used. Do NOT carry out work under a machine, which has been raised only with the three point linkage.
- The machine must not be supported using fragile elements (bricks or concrete blocks).
- After completing work associated with lubrication, remove excess oil or grease.
- In order to reduce the danger of fire the machine must be kept in a clean condition.

### **2.1.6 OPERATING THE MULTIFUNCTION ARM**

- Before starting the multifunction arm, make sure that there are no bystanders (especially children) or animals in the danger zone. The machine operator is obliged to ensure proper visibility of the machine and the working area.
- Before starting the working head drive, lower the working head to working position.
- Multifunction arm operation should begin after reaching nominal PTO speed of 1000 rpm. Do NOT overload the multifunction arm's hydraulic system and also do NOT engage the PTO suddenly.

- Do NOT leave the carrying vehicle cab, when the machine drive is engaged.
- Do NOT stand within the multifunction arm's working zone.
- Do NOT operate the working head while reversing. While reversing, raise the multifunction arm.
- Keep a safe distance from electric power lines during travel with raised multifunction arm.
- All the control panel operations should be performed only from the operator's seat in the carrying vehicle's cab. Operating the control panel outside the operator's cab is forbidden.
- Operation and transport of the multifunction arm is allowed only on slopes with the maximum inclination of 7°. However, due to changing location of centre of gravity depending on type of working head, type of carrying vehicle and length of telescopic multifunction arm, the allowable slope inclination angle may be smaller. That is why the user must exercise particular caution and determine by himself the maximum slope inclination angle for operating the multifunction arm.
- If the full reach of the multifunction arm is to be used, make sure that stability of the carrying vehicle will be maintained.
- While working on slopes, do not raise the working head more than 0,5 m above the ground.
- In the event of a tilt of the carrying vehicle with the multifunction arm, immediately lower the working head to the ground and stop the carrying vehicle.

### **2.1.7 OPERATION OF**

- While reversing and during turns, the PTO drive must be disengaged.
- The machine may only be connected to the implement carrier PTO by multiplier gear box recommended by the Manufacturer.
- Before starting the machine make sure that there are no bystanders (especially children) in the danger zone. The machine operator is obliged to ensure proper visibility of the machine and the working area.
- Before starting PTO, make certain that the PTO rotation direction is correct.

- Before disconnecting the multiplier gear box connection, turn off the carrying vehicle engine and remove the key from the ignition.
- Do NOT wear loose clothing, straps or whatever that may become wrapped round the rotating multiplier gear box connection. Contact with the rotating multiplier gear box connection may cause severe injuries.
- Do NOT go over and under the multiplier gear box connection or stand on it equally during work as also when the machine is parked.

## 2.2 RESIDUAL RISK

Pronar Sp. z o. o. in Narew has made every effort to eliminate the risk of accidents. There is, however, a certain residual risk, which could lead to an accident, and this is connected mainly with the actions described below:


- using the machine for purposes other than those for which it is intended,
- being between the carrying vehicle and the machine while the engine is running and when the machine is being attached,
- being on the machine while the engine is running,
- operating the multifunction arm with removed or faulty safety guards,
- not maintaining safe distance from the danger zone or being within the zones while the machine is operating,
- operation of the machine by persons under the influence of alcohol,
- cleaning, maintenance and technical checks when carrying vehicle is connected and engine is running.

The residual risk may be kept to a minimum by following the recommendations below:

- operate the machine in prudent and unhurried manner,
- sensibly apply the remarks and recommendations contained in the Operator's Manual,
- carry out repair and maintenance work in line with operating safety rules,
- repair and maintenance work should be carried out by persons trained to do so,
- use close fitting protective clothing,
- ensure unauthorised persons have no access to the machine, especially children.
- maintain a safe distance from forbidden or dangerous places
- do not climb on the machine when it is operating

## 2.3 INFORMATION AND WARNING DECALS









The multifunction arm is labelled with the information and warning decals mentioned in TABLE 2.1. The symbols are positioned as presented in FIGURE 2.1. Throughout the time it is in use, the user of the machine is obliged to take care that notices and warning and information symbols located on the machine are clear and legible. In the event of their destruction, they must be replaced with new ones. Safety decals are available from your PRONAR dealer or directly from PRONAR customer service. New assemblies, changed during repair, must be labelled once again with the appropriate safety signs. During multifunction arm cleaning do not use solvents which may damage the coating of information decals and do not subject them to action of strong water jets.






**FIGURE 2.1** Locations of information and warning decals

Meaning of symbols (TABLE 2.1)

**TABLE 2.1 Information and warning decals**

| ITEM | DECAL   | MEANING  |
|------|---|--|
| 1    |    | <p>Before starting work, carefully read the Operator's Manual.</p>   |
| 2    |    | <p>Before beginning maintenance or repairs, turn off engine and remove key from ignition.</p>  |
| 3    |    | <p>Take particular care while working near electric power lines. Danger of electric shock.</p>   |
| 4    |   | <p>Maximum allowable PTO shaft rotation speed is 1000 rpm.</p>   |
| 5    |  | <p>Danger of being struck. Do not stay within the reach of the multifunction arm and working head</p>  |
| 6    |  | <p>Danger of crushing foot of toes</p>   |
| 7    |  | <p>When implement is in use there must be no bystanders in designated areas. If any work is required in these areas, make sure the tractor is stationary, and whether the implement is disconnected from the power source.</p> |
| 8    |  | <p>Do not reach into crushing space because elements may move. Danger of crushing hands or fingers.</p>  |



| ITEM | DECAL   | MEANING  |
|------|---|--|
| 9    |  | Lubrication points                                     |
| 10   |  | Information decal<br>"Tighten every 24 hours, 1400 Nm" |
| 11   |  | Machine type   |



*SECTION*

**3**

---


**DESIGN AND  
OPERATION**

## 3.1 TECHNICAL SPECIFICATION

**TABLE 3.1 BASIC TECHNICAL DATA**

|  | Unit |   |
|--|------|---|
| <b>Dimensions</b>  |      |   |
| Total length in transport setting                        | mm   | 1100  |
| Width in transport setting:                              | mm   | 2400  |
| Height in transport setting:                             | mm   | 2020  |
| <b>Technical specification</b>                           |      |   |
| Weight (without working head)                            | kg   | 1080  |
| Method of hitching to universal carrying vehicle         | -    | DIN 76060 type A, type B or SETRA mounting plate                              |
| Electric power supply                                    | V    | 24  |
| Horizontal range of multifunction arm operation          | mm   | 4750  |
| Multifunction arm drive                                  | -    | Own hydraulic system driven by the carrying vehicle's PTO                     |
| Multifunction arm control                                | -    | Electrohydraulic – joystick and control panel installed in the operator's cab |
| Oil tank capacity  | l    | 120   |
| Power of working head drive system                       | kW   | 37,5  |
| Arm safeguard  |      | Hydraulic safety device   |
| Maximum arm rotation angle with safety device activation | °    | 20  |
| Working head rotation range                              | °    | 190   |
| Oil cooler   | -    | Standard  |

## 3.2 GENERAL DESIGN AND OPERATION



**FIGURE 3.1** General design of the multifunction arm.

(1)- linkage connection elements; (2)- multiplier gear box with hydraulic pumps; (3)- guide;  
 (4)- support system slide; (5)- support system arm;

(6)- working head connection; (7)- hydraulic tank; (8)- oil cooler; (9)-electrohydraulic selective control valve; (10)- control box of selective control valve; (11)- hydraulic cylinder; (12)- hydraulic accumulators; (13)- hydraulic motor of support system slide drive; (14)- hydraulic conduits; (15)- control panel and joystick.

Main elements of the multifunction arm:

- linkage
- working head support system
- hydraulic system
- control system

The main components of the multifunction arm's linkage (FIGURE 3.1) are connection elements (1) type A (acc. to DIN 76060), type B (acc. to DIN 76060) or SETRA type that are attached to the support frame of the multifunction arm and used for connecting with the mounting plate of the universal carrying vehicle's front linkage.

The multifunction arm design is based on the support frame to which the jointed arms of the support system (5) are connected through rotary hanger. The rotary hanger connected with rotation cylinder (hydraulic safety device) protects the multifunction arm against damage when the working head hits an obstacle and makes it possible to set the arms of the support system in transport position. At the end of the arm there is an attachment (6) (TYPE 80P) for fixing the working head. TYPE 60P attachment (with reduced width of the working head beam) and P0G01 adapter (for attaching the working head without the connecting beam) are available as options.

Slide (4) is connected with hydraulic motor (13) and enables movement of the support system on guide (3) to the left or right in relation to the carrying vehicle. The multifunction arm can work on the right and on the left side of the carrying vehicle (after manual rearrangement of securing elements and after turning the arm).

The multifunction arm is equipped with independent hydraulic system driven by the carrying vehicle's power take-off shaft (PTO) through multiplier gear box (2) with pumps supplying two circuits of the hydraulic system. One circuit of the hydraulic system is for positioning the arms and the working head while the other circuit is for driving the working head. Hydraulic pumps draw oil from independent oil tank (7) through oil suction filter and pump it into the two hydraulic circuits.

The hydraulic system is equipped with a hydraulic oil cooler (8) installed on oil return to tank. The oil cooler fan is powered by the carrying vehicle's electrical system through a wiring harness protected with a 15A fuse located next to the control box (10) of the selective control valve. The fan is switched on by the relay connected with the thermostat installed near the cooler when the allowed oil temperature in the cooler is exceeded and switched off when the optimum oil temperature is reached.

Working head support system consists of arms (5) that are moved by hydraulic cylinders (11). Hydraulic cylinders enable free manoeuvring of the arms of the multifunction arm to which the working head is attached. One of the arms has telescopic design, which increases working range of the working head.

Hydraulic cylinders are controlled by means of electrohydraulic selective control valve (9) by the carrying vehicle's driver using control panel and joystick (15).





*SECTION*

**4**

---

**CORRECT USE**

## 4.1 PREPARING FOR WORK

The manufacturer guarantees that the machine is fully operational and has been checked according to quality control procedures and is ready for use. This does not release the user from an obligation to check the machine's condition after delivery and before first use. The machine is delivered to the user completely assembled.



### ATTENTION

**Check technical condition of the multifunction arm before each use. In particular, check the technical condition of the suspension system, hydraulic system, drive system and the integrity of safety guards.**

Before hitching to the carrying vehicle, the machine operator must check the technical condition of the multifunction arm and prepare it for test start-up. In order to do this:

- the user must carefully read this Operator's Manual and observe all recommendations, understand the design and the principle of machine operation,
- check the condition of protective paint coat,
- inspect machine's individual components for mechanical damage resulting from incorrect transport (dents, piercing, bent or broken components),
- check all the lubrication points, lubricate the machine according to recommendations provided in section 5 "MAINTENANCE",



### ATTENTION

**Before beginning work lubricate all lubrication points.**

- check technical condition of the hydraulic system;
- check if working head, linkage and safety guards are correctly installed,
- check technical condition of hitching system and protective elements,
- check the hydraulic oil level in the hydraulic tank and multiplier gear box.

If all the above checks have been performed and there is no doubt as to the machine's good technical condition, it can be hitched to the carrying vehicle. Start the carrying vehicle's engine, check all systems and perform a test run before beginning work. In order to inspect:

- hitch the multifunction arm to the universal carrying vehicle (see "*HITCHING TO UNIVERSAL CARRYING VEHICLE*")
- start PTO drive of the universal carrying vehicle,
- set it in working position,

**DANGER**

Do NOT exceed the PTO rotation speed of 1000 rpm. Otherwise the multiplier gear box and hydraulic system of the multifunction arm may be damaged.

Engage multifunction arm's drive for 3 minutes and check the following:

- that there is no knocking or noise in the hydraulic pump drive system arising from scraping or grinding of metal elements,
- confirm that there are no oil leaks in the hydraulic system.
- confirm that the movement of the support system slide along the guide as well as other movements of the multifunction arm are performed smoothly and without jamming.

The multifunction arm's operation at no load should be smooth. Shaking of drive transmission is not acceptable, nor is abnormal noise and vibrations coming from loose nut and bolt connections. Confirm that oil does not leak from the hydraulic system.

**DANGER**

Before using the multifunction arm, the user must carefully read this Operator's Manual. Careless and incorrect use and operation of the multifunction arm, and non-compliance with the recommendations given in this operator's manual is dangerous to your health.

The multifunction arm must never be used by persons who are not authorised to drive carrying vehicles, including children and people under the influence of alcohol or other drugs.

Non-compliance with the safety rules of this Operator's Manual can be dangerous to the health and life of the operator and others.

Before starting the multifunction arm, make sure that there are no bystanders in the danger zone.

If any faults are detected they must be identified and rectified. If a fault cannot be rectified or the repair could void the warranty, please contact retailer for additional clarifications.

## 4.2 TECHNICAL INSPECTION

When preparing the multifunction arm for use, check individual elements according to guidelines presented in TABLE 4.1.

**TABLE 4.1 TECHNICAL INSPECTION SCHEDULE**

| DESCRIPTION   | MAINTENANCE ACTIVITIES  | FREQUENCY  |
|---|---|--|
| Correct mounting of the multifunction arm on the carrying vehicle's linkage | Check if correctly installed  | Daily before beginning work  |
| Technical condition of the multifunction arm's hydraulic system             | Check according to section "HYDRAULIC SYSTEM MAINTENANCE"                         |  |
| The oil level in the hydraulic oil tank and multiplier gear box             | Check according to section "HYDRAULIC SYSTEM MAINTENANCE"                         |  |
| Check if all main nut and bolt connections are properly tightened           | Check according to section "TIGHTENING OF BOLT AND NUT CONNECTIONS"               |  |
| Lubrication   | Lubricate the components according to section "LUBRICATION".                      |  |
| Replacement of oil filters  | According to section "5.2.1 OIL TANK AND OIL FILTERS"                             | Oil filter:<br>After the first 100 h and then, after activation of the filter clogging indicator<br>Oil suction filter:<br>Every 1000 h or once a year |
| Change of oil in tank   | According to section "5.2.1 OIL TANK AND OIL FILTERS"                             | Every 1000 h or once a year  |
| Change of oil in multiplier gear box  | According to section "5.2.2 MULTIPLIER GEAR BOX WITH HYDRAULIC OIL PUMP ASSEMBLY" | After the first 50 h, then every 1000 h or every 6 months  |



### ATTENTION

Do NOT use out of order multifunction arm.

## 4.3 HITCHING TO UNIVERSAL CARRYING VEHICLE

PRONAR WWP500UH multifunction arm can be hitched to universal carrying vehicle that meets the requirements contained in TABLE 1.1 "REQUIREMENTS FOR CARRYING VEHICLE".



### ATTENTION

Before hitching the multifunction arm to carrying vehicle, read the operator's manual of the carrying vehicle. Comply with the recommendations relating to linkage and mounting points.



### DANGER

Do NOT operate the multifunction arm with the carrying vehicle without the driver's cab. The carrying vehicle should be equipped with the cab protecting the operator against possible hazards.


The operator should also use personal protective equipment such as protective clothing, safety goggles, safety helmet to reduce the risk of injuries.



### DANGER

When hitching, there must be nobody between the machine and the carrying vehicle. Exercise caution when hitching the machine.


### 4.3.1 HITCHING THE MULTIFUNCTION ARM TO THE CARRYING VEHICLE'S LINKAGE



**FIGURE 4.1** Connection elements of the multifunction arm's linkage.

(A)- connection elements DIN 76060 type A; (B)- connection elements DIN 76060

type B; (C)- SETRA type connection elements; (1)- connecting hooks; (2)- fixing bolts; (3)- guides.



**FIGURE 4.2 Connecting the multifunction arm's multiplier gear box to the carrying vehicle's PTO.**

(1)- articulated connector; (2)- bolts fixing the multiplier gear box bracket to the frame; (3)- bolts fixing the multiplier gear box to the bracket

In order to hitch the multifunction arm to the carrying vehicle's linkage, proceed as follows:

- Immobilize the universal carrying vehicle and prevent it from moving;
- Raise the multifunction arm mounted on the stand using a forklift truck and bring the multifunction arm to the carrying vehicle's linkage in such a manner as to ensure that the hooks (1) (FIGURE 4.1) of the multifunction arm's linkage are located above the catches of the mounting plate of the carrying vehicle's linkage;
- Lower the multifunction arm so as to ensure that the hooks (1) engage the catches of the mounting plate of the carrying vehicle's linkage;
- Secure the connection between the multifunction arm's linkage and the mounting plate of the carrying vehicle's linkage using fixing bolts (2);
- Loosen the bolts (2) (FIGURE 4.2) fixing the multiplier gear box bracket to the frame and the bolts (3) fixing the multiplier gear box to the bracket;
- Connect the multiplier gear box to the carrying vehicle's PTO shaft end using the articulated connector (1). Choose the position with the smallest working angles of the

articulated joints. Slide the connector onto the carrying vehicle's PTO shaft end until resistance is felt and then, slide the connector back by 5 to 10 mm.




## DANGER

Turn off the carrying vehicle's engine and remove the key from the ignition before connecting the carrying vehicle's front PTO to multifunction arm multiplier gear box. Ensure that unauthorised persons do not have access to the carrying vehicle cab.

- Tighten the bolts (2) fixing the multiplier gear box bracket to the frame and the bolts (3) fixing the multiplier gear box to the bracket using proper tightening torque;
- Dismount the multifunction arm stand, drive the forklift truck with the stand away and leave the multifunction arm suspended on the carrying vehicle;

### 4.3.2 CONNECTING THE CARRYING VEHICLE'S ELECTRICAL SYSTEM


The multifunction arm's electrical system is designed for 24V DC supply.



**FIGURE 4.3** Connecting the multifunction arm's electrical system.

(1)- power supply wiring harness; (2)- connection lead; (3)- connection socket of the multifunction arm's electrical system; (4)- connection socket of the control panel's wiring harness; (5)- control panel's wiring harness; (6)- control panel; (7)- joystick

In order to cooperate with the multifunction arm, the carrying vehicle should be equipped with the power supply wiring harness (1) (FIGURE 4.3) with a 3-pin electric socket to which the multifunction arm's electrical system should be connected using the connection lead (2).



**FIGURE 4.4** Installation diagram of the power supply wiring harness on the carrying  
 (1) – 3-pin electric socket; (2) – power supply wiring harness; (3) – battery; (4) - UNIVAL  
 30A fuse.

The power supply wiring harness (2) (FIGURE 4.4) should be installed by a properly qualified person according to the instructions of the carrying vehicle manufacturer. The power supply wiring harness is equipped with a 30A fuse (4).

**ATTENTION**

When installing the power supply wiring harness on the carrying vehicle (FIGURE 4.4), ensure correct polarity of the power supply socket (1). The battery reversed polarity may cause damage to the multifunction arm's electrical system.

**DANGER**

Prior to connecting the electrical system leads, the user must carefully read the operator's manual of the carrying vehicle and observe all recommendations of the Manufacturer.

**ATTENTION**

During operation, the electrical leads should be routed so that they do not get entangled in moving machine and carrying vehicle parts and should be protected against damage during the multifunction arm operation.



**ATTENTION**


**Work on electrical system must be carried out by suitably qualified personnel.**

When the power supply wiring harness (1) (FIGURE 4.3) is installed on the carrying vehicle, the multifunction arm can be connected with the carrying vehicle's electrical system using the connection lead (2).

Connect the control panel (6) and joystick (7) to the control panel's wiring harness (5). Then, connect the wiring harness plug (5) to the connection socket (4) of the multifunction arm's electrohydraulic system, install control panel (6) and joystick (7) inside the carrying vehicle's cab in the place which makes it possible to manoeuvre the control levers freely from the seat of the carrying vehicle operator. The control panel and joystick should be mounted in a stable manner, without weakening the protective structure of the carrying vehicle

## 4.4 BALLASTING THE CARRYING VEHICLE

The rear axle of the carrying vehicle with the multifunction arm mounted should be ballasted. Amount of additional ballast can be calculated using the following formula (FIGURE 4.5).



**FIGURE 4.5** Ballasting the carrying vehicle

*A* - distance between the multifunction arm's centre of gravity and the front axle; *B* - carrying vehicle axle base; *P* - weight of multifunction arm with working head; *T* - additional ballast

## 4.5 START AND OPERATION OF THE MULTIFUNCTION ARM BY MEANS OF THE CONTROL SYSTEM

Once the multifunction arm is hitched to the carrying vehicle, you may start the machine.

### DANGER



The multifunction arm may only be started when all its protection guards are installed properly.

Before engaging PTO drive make sure that there are no bystanders, especially children, near the multifunction arm.

### ATTENTION



Before operating the multifunction arm, lubricate all the lubrication points until the lubricant appears between the shaft and the bearing housing.

Engage the carrying vehicle's rear PTO drive at a suitably low engine speed and then gradually increase the speed until PTO speed of 1000 rpm is reached. When the proper PTO speed is reached, one may commence work with the multifunction arm.

### DANGER




Do NOT exceed the PTO rotation speed of 1000 rpm. Otherwise the multiplier gear box and hydraulic system of the multifunction arm may be damaged.

The arms of the multifunction arm and the working head are controlled by means of the control panel (FIGURE 4.6) and joystick (FIGURE 4.7) inside the carrying vehicle.

### ATTENTION



All the control panel and joystick operations should be performed only from the operator's seat in the carrying vehicle's cab. Operating the control panel and the joystick outside the operator's cab is forbidden.



**FIGURE 4.6 Control panel of multifunction arm.**


(1)- emergency stop (mushroom push-button); (2)- control system activation push-button and indicator light; (3)- activation push-button and indicator light of the arm shock absorbing function; (4)- activation push-button and indicator light of working head's floating function; (5)- activation push-button and indicator light of the working head drive; (6)- safety device activation indicator light; (7)- oil filter contamination indicator light; (8)- oil temperature indicator light; (9)- indicator light of oil level in the tank; (10)- main power supply switch of control panel.

Before manoeuvring the multifunction arm, switch on the main power supply switch of control panel (10) (FIGURE 4.6) and activate control panel by depressing push-button (2) for about 3 seconds. Activation of the control system is signalled by the indicator light above the activation push-button.

The hydraulic drive of the working head is switched on by depressing the push-button (5). When the arm shock absorbing function is required, press push-button (3). When ground surface tracking is required for the working head, press push-button (4) of the working head's floating function.

When immediate emergency stopping of the multifunction arm is required, press emergency stop (red mushroom push-button) (1) on the control panel. This push-button switches off the complete control system.

The multifunction arm movements are controlled by means of the joystick. The pictogram placed on the joystick mounting (FIGURE 4.7) shows the joystick control diagram.



**FIGURE 4.7** Controlling individual hydraulic cylinders of the multifunction arm by means of the joystick.

(A), (B), (C), (D), (E)- controlling the hydraulic cylinders of the multifunction arm; (F)- controlling the hydraulic motor shifting the arm along the guide; (1)- function push-button of the joystick (blue); (2)- function push-button of the joystick (red).

Individual functions of the joystick (FIGURE 4.7):

- (F) tilt the joystick to the right or left to start the hydraulic motor shifting the multifunction arm along the guide to the right or left;
- (C) tilt the joystick to the right or left while pressing the function push-button (1) to actuate the hydraulic cylinder extending the telescopic arm of the multifunction arm;
- (D) tilt the joystick to the right or left while pressing the function push-button (2) to actuate the hydraulic cylinder tilting the working head;
- (A) tilt the joystick forward or backward to actuate the hydraulic cylinder tilting the main arm of the multifunction arm;
- (E) tilt the joystick forward while pressing the function push-button (1) to actuate the hydraulic cylinder of the safety device causing the return of the safety device cylinder piston to start position.
- (B) tilt the joystick forward or backward while pressing the function push-button (2) to actuate the hydraulic cylinder tilting the telescopic arm;

## 4.6 ATTACHING THE WORKING HEAD

WWP500UH multifunction arm can be connected with working heads compatible with the working head connection and the hydraulic system of the multifunction arm.



### ATTENTION

Before attaching the working head, the user must carefully read the operator's manuals of the working head, carrying vehicle and multifunction arm and observe all instructions contained in the manuals.



### DANGER


When hitching, there must be nobody between the machine and the carrying vehicle. Exercise caution when hitching the machine.



### DANGER

Before attaching the working head, turn off the carrying vehicle's engine and remove the key from the ignition. Ensure that unauthorised persons do not have access to the carrying vehicle cab.

Check technical condition of the working head's guards and general technical condition of the machine.



**FIGURE 4.8 Attaching the working head to the multifunction arm.**

(1)- working head attachment holder; (2)- working head attachment lock; (3)- clamping bolts; (4)- nuts; (5),(6)- washers; (7)- P0G01 adapter (option); (A)- hydraulic quick coupler (socket); (B)- hydraulic quick coupler (socket); (C)- hydraulic quick coupler (plug).

In order to hitch the working head to the multifunction arm head (FIGURE 4.8), proceed as follows:



- Bring the holder (1) of the multifunction arm's working head attachment to the working head attachment (support beam).
- Using the control system, position the multifunction arm's working head attachment holder (1) at the same height as the working head's attachment (support beam).
- Turn off the carrying vehicle's engine and prevent the carrying vehicle from moving.
- Connect the holder (1) of the multifunction arm's working head attachment to the working head's attachment (support beam) by means of the attachment lock (2). Screw the entire assembly together with four fixing bolts (3).
- In the case of working heads without the support beam, use the optional P0G01 adapter (7).
- Connect the hydraulic quick couplers (A), (B) and (C) of the multifunction arm with the corresponding quick couplers of the working head's hydraulic conduits.
- Turn on the carrying vehicle's engine and the multifunction arm's drive. Raise the working head using the control panel of the multifunction arm.

**DANGER**

Prior to connecting individual hydraulic system conduits, the user must carefully read the operator's manual of the multifunction arm and working head and observe all recommendations of the Manufacturer.

**DANGER**

When connecting the hydraulic quick couplers to the working head, make sure that the hydraulic system of the multifunction arm is not under pressure.

## 4.7 TRANSPORTING THE MACHINE

### ATTENTION




Before driving on public roads in order to transport the multifunction arm to the work site and back, the multifunction arm shall be folded to its transport position.

When driving on public roads, comply with the road traffic regulations in force in the country in which the machine is used.

Before driving onto a public road, check if all the lights and warning plates on the carrying vehicle are properly mounted and visible.

The multifunction arm may not be used or transported in conditions of limited visibility.



**FIGURE 4.9** Transport position of the multifunction arm

(1)- working head hitch; (2)- working head connection

For transport to place of work and back, set the multifunction arm in transport position (FIGURE 4.9) so that the multifunction arm width is minimal and the height measured from the road surface does not exceed the permissible height (4 metres) stipulated by the road traffic regulations. In this position, working head connection (2) is mounted on working head hitch (1).

**DANGER**

During transport, pay special attention and exercise particular caution when driving the carrying vehicle with the multifunction arm under viaducts, bridges and electric power lines.

**DANGER**

The drive of the working head shall not be turned on when the multifunction arm is in its transport position.

## 4.8 SETTING THE MULTIFUNCTION ARM IN WORKING POSITION AND OPERATION

To set the multifunction arms in working position:

- start the front PTO drive of the universal carrying vehicle;
- switch on the main power supply switch of control panel (10) (FIGURE 4.6) and activate control panel by depressing push-button (2) for about 3 seconds. Activation of the control system is signalled by the indicator light above the activation push-button.
- operate appropriate hydraulic cylinders of the multifunction arm (FIGURE 4.7) in order to place the working head in the working area;
- After setting the working head in working position, engage working head drive by pressing push-button (5) on the control panel (FIGURE 4.6). Ramp time for activation of working head drive is about 2 seconds.

### DANGER



The working head may only be started when all the protection guards of the multifunction arm and working head mounted properly and the working head is in its working position.

Bystanders should be at a safe distance from the multifunction arm's working head during work because of the risk of injury caused by thrown objects (stones, branches etc.).

- engage appropriate carrying vehicle gear and start working.

During operation, the multifunction arm operator must ensure proper visibility of the machine and work area so that the operator can see obstacles and possible dangers in the route of the working head. The rotating elements of the working head should never be directed towards the carrying vehicle.

### DANGER



NEVER work if the rotating elements of the working head are directed towards the carrying vehicle. Otherwise the carrying vehicle may be damaged or the operator may be injured.

While operating the multifunction arm, adjust the carrying vehicle's speed. The speed depends on a number of factors. The main ones are:


- the working head type used
- the type of the material along which the working head moves
- the type and configuration of the ground along which the carrying vehicle travels
- weather conditions.

In all those cases, use the lowest possible speed of the carrying vehicle at constant engine speed so that the carrying vehicle's PTO rotation speed is fixed and equal to 1000 rpm.



### DANGER

During operation with the arm of the multifunction arm raised, keep the arms and working head at a safe distance from overhead power lines (FIGURE 4.7).



**FIGURE 4.10 Safe distances of the machine from power lines.**

In line with regulations in force, it is not acceptable to place work stations, machines or devices directly below overhead power lines or at a distance, calculated horizontally from extreme lines, lower than (FIGURE 4.10):

- 3 m - for lines with rated voltage up to 1 kV,

- 5 m - for lines with rated voltage above 1 kV and up to 15 kV,
- 10 m - for lines with rated voltage above 15 kV and up to 30 kV,
- 15 m - for lines with rated voltage above 30 kV and up to 110 kV,
- 30 m - for lines with rated voltage above 110 kV.

If it is impossible to keep the minimum distances in order to work safely in the vicinity of power lines, then apply to the nearest Power Utility and have the lines deenergised for the duration of operation.

### ATTENTION



Operation and transport of the carrying vehicle with hitched multifunction arm is allowed only on slopes with the maximum inclination of 7°. However, due to changing location of centre of gravity depending on type of working head, type of carrying vehicle and length of multifunction arm, the allowable slope inclination angle may be smaller. That is why the user must exercise particular caution and determine by himself the maximum slope inclination angle for operating the carrying vehicle with the multifunction arm.


If the full reach of the multifunction arm is to be used, make sure that stability of the carrying vehicle will be maintained.

While working on slopes, do not raise the working head more than 0,5 m above the ground.

In the event of a tilt of the carrying vehicle with the multifunction arm, immediately lower the working head to the ground and stop the carrying vehicle.

When the working head moves along an uneven ground and the ground surface tracking function is required, switch on the floating position function for the working head titling by means of push-button (4) (FIGURE 4.6). At the time, the head changes its titling position smoothly and adjusts its setting to the ground irregularity (D) (FIGURE 4.11).

When the working head is operated at the ground level and requires the function of tracking the ground surface along which it moves in the vertical plane, enable the arm shock absorbing function using push-button (5) (FIGURE 4.6). At the time, the arm of the multifunction arm changes its vertical position smoothly and adjusts the head's setting to the ground irregularities (B) (FIGURE 4.11).



**FIGURE 4.11 Arm shock absorbing function and head tilt floating position function.**

(A)- operation of the working head with the arm shock absorbing function disabled; (B)- operation of the working head with the arm shock absorbing function enabled; (C)- operation of the working head with the head tilt floating position function disabled; (D)- operation of the working head with the head tilt floating position function enabled.

When the working head is being operated with the arm of the multifunction arm raised, disable the working head's tilt floating position and the arm shock absorbing function.

When the multifunction arm with working head is raised, always start operating the working head at the highest point and move the head gradually downward. When the operation of the working head involves the falling of diverse plant material (branches) from a height, secure the work site so that no one is present in the zone of operation of the head and of the falling plant material.



## DANGER

Bystanders should be at a safe distance from the multifunction arm's working head during operation with the arm raised because of the risk of diverse material (stones, branches etc.) falling and being thrown by the head.

While operating the multifunction arm, pay attention to uneven surface and obstacles on the route of moving multifunction arm. When an obstacle is encountered, the main arm rotates, the safety device activation indicator light (6) lights up (FIGURE 4.6) and the acoustic signal is emitted. In such a case, stop the carrying vehicle as quickly as possible and bypass the obstacle with the working head raised and then, using the joystick, rotate the main arm of the

multifunction arm causing the return of the safety device cylinder piston to start position. Then, the safety device activation indicator light (6) and the acoustic signal should be OFF.

When driving across the road, pavement or other obstacles and when making turns, raise the working head and disengage the working head drive.

Be especially careful when mowing along ditches, furrows and slopes. If overheating of the multifunction arm hydraulic system occurs during operation of the working head, disengage the PTO drive and find the cause of overload.

Overheating of the hydraulic system is indicated by the oil temperature warning light (8) (FIGURE 4.6) on the control panel. Oil cooler fan is turned on when this occurs. If the oil temperature does not drop within 10 min, working head drive is turned off. When the light goes out, you can turn on the working head drive again.

When immediate emergency stopping of the multifunction arm is required, press emergency stop (red mushroom push-button) (1) (FIGURE 4.6) on the control panel. This push-button switches off the complete control system.

After finishing work, turn off the main power supply switch (10) (FIGURE 4.6) of the control panel.



### **HIGH NOISE LEVEL WARNING**

Depending on working conditions, the carrying vehicle with the machine may generate noise exceeding the level of 85dB at the operator position. In such conditions the operator should use personal protective equipment (ear protectors).

In order to reduce the level of noise during work, the operator cab windows and door should be closed.



*SECTION*

**5**

---

**MAINTENANCE**

## 5.1 HYDRAULIC SYSTEM MAINTENANCE



### DANGER

Before commencing whatever work on hydraulic system reduce the pressure in the system.



### DANGER

During work on hydraulic system, use the appropriate personal protection equipment i.e. protective clothing, footwear, gloves and eye protection. Avoid contact of skin with oil.

Make sure that the oil in the multifunction arm hydraulic system is of adequate grade. Do not add hydraulic oil of other grade. The hydraulic system in a new multifunction arm is filled with HL46 hydraulic oil.



### ATTENTION

The condition of hydraulic system should be inspected regularly while using the machine.

Flexible hydraulic conduits should not be entwined or fractured.

The hydraulic system should be completely tight sealed. Inspect the seals when hydraulic cylinders are completely extended. If oil leak is detected on hydraulic cylinder body, ascertain origin of leak. Minimum leaks are permissible with symptoms of "sweating", however in the event of noticing leaks in the form of "droplets" stop using the machine until faults are remedied.

In the event of oil leak on hydraulic conduit connections, tighten connections, and if this does not remedy faults then change conduit or connection elements. Always exchange each mechanically damaged component. Also, pay attention to ensure that flexible hydraulic conduits are not fractured.



Flexible hydraulic conduits should be replaced after 4 years of use.

**TABLE 5.1 HL46 hydraulic oil characteristics**


| ITEM | NAME                                | VALUE                          |
|------|-------------------------------------|--------------------------------|
| 1    | ISO 3448VG viscosity classification | 46                             |
| 2    | Kinematic viscosity at 40°C         | 41.4 ÷ 50.6 mm <sup>2</sup> /s |
| 3    | ISO 6743/99 quality classification  | HL                             |
| 4    | DIN 51502 quality classification    | HL                             |
| 5    | Flash-point                         | above 220 °C                   |

Because of its composition, the oil is not classified as a dangerous substance, however long-term action on the skin or eyes may cause irritation. In the event of contact of oil with skin wash the place of contact with water and soap. Do NOT apply organic solvents (petrol, kerosene). Contaminated clothing should be changed to prevent access of oil to skin. In the event of contact of oil with eye, rinse with large quantity of water and in the event of the occurrence of irritation consult a doctor. Hydraulic oil in normal conditions is not harmful to the respiratory tract. A hazard only occurs when oil is strongly atomised (oil vapour), or in the case of fire during which toxic compounds may be released. Oil fires should be quenched with carbon dioxide (CO<sub>2</sub>), foam or extinguisher steam. Do NOT use water for fire extinguishing.

Spilt oil should be immediately collected and placed in a marked tight container. Used oil should be taken to the appropriate facility dealing with recycling or regeneration of oils.

### 5.1.1 OIL TANK AND OIL FILTERS


The oil tank (1) (FIGURE 5.1) holds 120 l of hydraulic oil type HL46. Check tank welded joints and hydraulic hoses for leaks every day.



**FIGURE 5.1 Oil tank**

*(1) - oil tank; (2) - oil filler cap; (3) - strainer; (4) - oil level indicator; (5) - drain plug.*

Change the oil in the tank after every 1000 hours of operation of the multifunction arm or once a year, whichever occurs first. To change the oil in the tank, unscrew the filler plug (2) and then unscrew the drain plug (5) to drain oil to a previously prepared container. Pour fresh oil into the tank through the strainer (3) in the tank filler opening having previously screwed the drain plug (5) in.



**FIGURE 5.2 Oil filters in the hydraulic system.**

*(1)- oil filter on the oil return to the tank; (2)- oil suction filter; (3)- tank inlet cover.*



**While changing oil in the tank, always change the suction filter (2) inside the tank and the filter (1) on the oil return to the tank.**

Before pouring oil in, change the suction filter (2) (FIGURE 5.2) inside the oil tank.

Replace the suction filter (2) (inside the oil tank) every 1000 hours of operation of the multifunction arm or once a year while changing oil in the tank, whichever occurs first. To this end, unscrew the tank inlet cover (3) and through the opening in the tank unscrew the oil suction filter (2).

The oil filter (1) is located on the oil return to the tank. Filter clogging sensor fitted in the filter housing triggers a light indicator on the multifunction arm control panel (7) (FIGURE 4.6) or the filter clogging level can be checked on the sight glass located on the filter (depending on filter version). Replace the filter each time the filter clogging light indicator is activated.

If the oil filter is not changed after activation of the filter clogging light indicator (7), the power supply of the control system will be switched off after 5 minutes of operation with the clogged filter (the system will switch to standby mode).

The filter should be replaced for the first time after 100 hours of multifunction arm operation regardless of whether the sensor indicates a clogged filter. Replace the oil filter (1) also when changing oil in the tank. In order to change filter:

- unscrew the clogged filter housing;
- cover sealing ring of new filter with oil (a few drops);
- screw in new filter until sealing ring and casing make contact and then screw in by hand making one more half turn (do not screw in too tightly).

### ATTENTION




**When unscrewing used suction filter (2) or oil filter (1) (FIGURE 5.2), do not use hammer, chisel etc. as this may damage the filter body. Use filters recommended by the machine manufacturer (original filters).**

**Screw in filter by hand, without use of any tools.**

Each time you change the oil and filters and during the daily checks of the multifunction arm hydraulic system, check the oil level on the tank sight glass (4) (FIGURE 5.1). Sight glass float indicator should be near the top. Oil indicator has a minimum oil level sensor. If the light (9) (FIGURE 4.6) lights up on the multifunction arm control panel, add the oil to the required level.

### 5.1.2 MULTIPLIER GEAR BOX WITH THE HYDRAULIC OIL PUMP ASSEMBLY



**FIGURE 5.3 Multiplier gear box with hydraulic pump and viscosity classification of gear oils depending on the ambient temperature.**

(A)- multiplier gear box; (B)- hydraulic pumps assembly; (1)- oil filler plug; (2)- sight-glass; (3)- drain plug; (4)- air vent.

There must be no oil leaks from the multiplier gear box (A) and pumps (B) (FIGURE 5.3). These can be stopped by tightening the mounting bolts or replacing the seals. If needed, remove the oil filler cap (1) or air vent (4) and add gear oil to sight-glass level (2). To change the oil, unscrew the drain cap (3) and drain the oil into a prepared vessel. Then pour oil into the multiplier gear box through the filler plug (1) or air vent (4) to the level of the sight-glass (2).

#### NOTE



ISO L-CKC or API GL-3/GL-5 quality grade gear oil may be used. The viscosity grade of the gear oil is selected depending on the ambient temperature (FIGURE 5.3).


As a standard, the multiplier gear box is filled with gear oil of API GL-3 / GL-5 quality grade and SAE 90 viscosity grade.

#### NOTE



Tighten the G3/8" plugs (drain plug, filler plug, sight-glass and air vent of the multiplier gear box) with 30 Nm (+/- 2 Nm) torque.

### 5.1.3 ELECTROHYDRAULIC SELECTIVE CONTROL VALVES



**FIGURE 5.4 Electrohydraulic selective control valves.**

(1) - electrohydraulic selective control valve of cylinders of support system arms; (2) - electrohydraulic selective control valve of the working head's hydraulic motor.

The electrohydraulic selective control valve (1) (FIGURE 5.4) is used to control the five hydraulic cylinders of the support system. Single-section selective control valve (2) starts the working head's hydraulic motor. Selective control valves are controlled by means of control panel from the carrying vehicle's cab. Condition of seals of selective control valves should be checked daily.

#### ATTENTION




Each electrohydraulic selective control valve is equipped with overflow valves that are set in the factory by the Manufacturer for proper working pressure of the multifunction arm's hydraulic system.

Do NOT adjust overflow valves because it may lead to damage to the multifunction arm's hydraulic system and working head. Adjustment of overflow valves should be carried out by an authorised service station of the machine manufacturer.



## 5.2 LUBRICATION




**FIGURE 5.5** Location of lubrication point pictograms.



When using the machine the user is obliged to observe lubrication instructions according to attached schedule. Excess lubricant causes depositing of additional contaminants in places requiring lubrication, therefore it is essential to keep individual machine components clean.

Grease all grease nipples (FIGURE 5.5) located on the machine in places marked with the following pictogram:



The lubrication points are the following: all the hinge pins of the support system, hydraulic cylinder eyes, extending arm of support system, chain of slide drive mechanism and slide of support system.

Machine lubrication should be performed with the aid of a manually or foot operated grease gun, filled with generally available grease. Before commencing lubrication insofar as is possible remove old grease and other contamination. Remove and wipe off excess oil or grease

## 5.3 TIGHTENING BOLT CONNECTIONS

Before each use of the machine and during maintenance and repair work, confirm that all bolt connections are properly tightened. If any clearances in bolt connections are found, tighten bolt connections using appropriate tightening torque (TABLE 5.2), unless other tightening parameters are given. Recommended tightening torque values apply to non-greased steel bolts.




### ATTENTION

Should it be necessary to change individual parts, use only original parts or those indicated by the Manufacturer. Non-adherence to these requirements may put the user and other people's health and life at risk, and also cause damage to the machine.



### ATTENTION

The bolt fixing the safety device arm to the mast should be tightened every 24 hours using the tightening torque of 1400 Nm (FIGURE 5.6).



**FIGURE 5.6** Bolt fixing the safety device arm to the mast.

(1)- bolt

**TABLE 5.2 TIGHTENING TORQUE FOR NUT AND BOLT CONNECTIONS**

| THREAD<br>DIAMETER<br>[mm] | 5.8                    | 8.8   | 10.9  |
|----------------------------|------------------------|-------|-------|
|                            | TIGHTENING TORQUE [Nm] |       |       |
| M6                         | 8                      | 10    | 15    |
| M8                         | 18                     | 25    | 36    |
| M10                        | 37                     | 49    | 72    |
| M12                        | 64                     | 85    | 125   |
| M14                        | 100                    | 135   | 200   |
| M16                        | 160                    | 210   | 310   |
| M20                        | 300                    | 425   | 610   |
| M24                        | 530                    | 730   | 1 050 |
| M27                        | 820                    | 1 150 | 1 650 |
| M30                        | 1050                   | 1 450 | 2 100 |
| M32                        | 1050                   | 1 450 | 2 100 |

## 5.4 STORAGE

After completed work, the multifunction arm should be carefully cleaned and washed with a water jet. While washing, do not direct a strong water or steam jet at information and warning decals, bearings, hydraulic conduits and wiring harnesses. Nozzle of pressure or steam washer should be kept at a distance of not less than 30 cm from cleaned surface.

After cleaning, inspect the whole machine, inspect technical condition of individual elements. Used or damaged elements should be repaired or replaced.

In the event of damage to the paint coat, clean rust and dust from damaged area, degrease and then paint with undercoat and after it is dry paint with surface coat paint retaining colour uniformity and even thickness of protective coating. Until the time of touch-up painting, the damaged place may be covered with a thin layer of grease or anticorrosion preparation. Multifunction arm should be kept in a closed or roofed building.

If the multifunction arm shall not be used for a long period of time, protect it against adverse weather conditions. Lubricate the multifunction arm according to the instructions provided. In the event of a prolonged work stoppage, it is essential to lubricate all components regardless of the date of the last lubrication. Protect against corrosion all cooperating elements i.e. pins, articulated joints, hydraulic cylinder pistons, guides of support system slide. Cover them with a thin layer of grease.

The multifunction arm should be stored in a roofed building inaccessible for children and animals. The multifunction arm unhitched from the carrying vehicle should be placed on the stand, on level, sufficiently hard surface in such a manner as to ensure that it is possible to hitch it again. The arms of the multifunction arm should be placed in transport position. The multifunction arm's control panel and joystick should be dismantled from the carrying vehicle's cab and protected against adverse weather conditions.

## 5.5 TROUBLESHOOTING

**TABLE 5.3 TROUBLESHOOTING**

| <b>TYPE OF FAULT</b>                            | <b>CAUSE</b>   | <b>REMEDY</b>   |
|---|--|---|
| It is impossible to control support system arms | Control panel is damaged                             | Repair at an authorised service point                                 |
|   | Multifunction arm's hydraulic system is out of order | Check individual elements of the multifunction arm's hydraulic system |
|   | Burnt out fuse                                       | Replace the fuse on the power supply wiring harness                   |
| Overheating of the multiplier gear box          | Incorrect oil level                                  | Check oil level.  |
|   | Damaged bearings                                     | Repair at an authorised service point                                 |
| It is impossible to start the working head      | Control panel is damaged                             | Repair at an authorised service point                                 |
|   | Selective control valve is damaged                   | Repair at an authorised service point                                 |
|   | Hydraulic pump is damaged                            | Repair at an authorised service point                                 |
| Oil cooler fan does not turn on                 | No power   | Check the supply voltage  |
|   | Faulty temperature sensor                            | Replace the sensor  |
|   | Burnt out fuse                                       | Replace the fuse on the power supply wiring harness of the fan        |

# NOTES

A series of horizontal dotted lines for writing notes.

