



PRONAR Sp. z o.o.

17-210 NAREW, UL. MICKIEWICZA 101A, PODLASKIE PROVINCE

phone:	+48 085 681 63 29	+48 085 681 64 29
	+48 085 681 63 81	+48 085 681 63 82
fax:	+48 085 681 63 83	+48 085 682 71 10


www.pronar.pl

OPERATOR MANUAL

MULTI-FUNCTION ARM

PRONAR WWT600 / WWT604D

TRANSLATION OF THE ORIGINAL COPY OF THE MANUAL



EDITION 2B-11-2018

PUBLICATION NO. 21N-00000000-UM



MULTI-FUNCTION ARM

PRONAR WWT600 / WWT604D

MACHINE IDENTIFICATION

SYMBOL /TYPE:

SERIAL NUMBER:

--	--	--	--	--	--

INTRODUCTION

Information in this document is current at date of publication. As a result of improvements, some numerical values and illustrations in this publication may not correspond to the actual specification of the machine supplied to the user. The manufacturer reserves the right to introduce design changes in machines produced that facilitate and improve the quality of machine operation, without making minor amendments to this Operator Manual.

This Operator Manual is an integral part of the machine documentation. Before using the machine, the user must carefully read this Operator Manual and observe all recommendations. This guarantees safe operation and ensures failure-free work of the machine. The machine is designed to meet obligatory standards, documents and legal regulations currently in force.

The manual describes the basic principles of safe use and operation of multifunction arm PRONAR WWT600 / WWT604D. If the information in this Operator Manual needs clarification, refer for assistance to the sale point where the machine was purchased or to the Manufacturer.

MANUFACTURER'S ADDRESS:

*PRONAR Sp. z o.o.
ul. Mickiewicza 101A
17-210 Narew*

CONTACT TELEPHONES

<i>+48 085 681 63 29</i>	<i>+48 085 681 64 29</i>
<i>+48 085 681 63 81</i>	<i>+48 085 681 63 82</i>

SYMBOLS APPEARING IN THIS OPERATOR MANUAL

Information, descriptions of danger and precautions and also recommendations and prohibitions associated with user safety instructions are marked:



and also preceded by the word "**DANGER.**" Failure to observe the instructions may endanger the machine operator's or other person's health or life.

Vital information and instructions that must be observed are by the symbol:



and also preceded by the word "**IMPORTANT**". Failure to observe the instructions may lead to damage to the machine as a result of improper operation, adjustment or use.

In order to focus the user's attention on the need to perform maintenance, the relevant section of the Operator Manual is marked with the pictogram:



Additional tips and advice for machine operation are marked with the sign:



and also preceded by the word "**TIP**".

DIRECTIONS USED IN THIS OPERATOR MANUAL

Left side – side to the left hand of the operator facing in the direction of machine's forward travel.

Right side – side to the right hand of the operator facing in the direction of machine's forward travel.



PRONAR Sp. z o.o.

ul. Mickiewicza 101 A
17-210 Narew, Polska

tel./fax (+48 85) 681 63 29, 681 63 81, 681 63 82,
681 63 84, 681 64 29

fax (+48 85) 681 63 83

http://www.pronar.pl

e-mail: pronar@pronar.pl

EC DECLARATION OF CONFORMITY OF THE MACHINERY

PRONAR Sp. z o.o. declares with full responsibility, that the machine:

Description and identification of the machinery	
Generic denomination and function:	Multifunction arm
Type:	WWT600
Model:	—
Serial number:	
Commercial name:	Multifunction arm PRONAR WWT600

to which this declaration relates, fulfills all the relevant provisions of the Directive **2006/42/EC** of The European Parliament and of The Council of 17 May 2006 on machinery, and amending Directive 95/16/EC (Official Journal of the EU, L 157/24 of 09.06.2006).

The person authorized to compile the technical file is the Head of Research and Development Department at PRONAR Sp. z o.o., 17-210 Narew, ul. Mickiewicza 101A, Poland.

This declaration relates exclusively to the machinery in the state in which it was placed on the market, and excludes components which are added and/or operations carried out subsequently by the final user.

Narew, the 2015-12-09

Place and date

Z-CIA DYREKTORA
d/s technicznych
członek zarządu

Roman Ormelianuk

*Full name of the empowered person
position, signature*



PRONAR Sp. z o.o.

ul. Mickiewicza 101 A

17-210 Narew, Polska

tel./fax (+48 85) 681 63 29, 681 63 81, 681 63 82,
681 63 84, 681 64 29

fax (+48 85) 681 63 83

http://www.pronar.pl

e-mail: pronar@pronar.pl

EC DECLARATION OF CONFORMITY OF THE MACHINERY

PRONAR Sp. z o.o. declares with full responsibility, that the machine:

Description and identification of the machinery	
Generic denomination and function:	Multifunction arm
Type:	WWT604D
Model:	—
Serial number:	
Commercial name:	Multifunction arm PRONAR WWT604D

to which this declaration relates, fulfills all the relevant provisions of the Directive **2006/42/EC** of The European Parliament and of The Council of 17 May 2006 on machinery, and amending Directive 95/16/EC (Official Journal of the EU, L 157/24 of 09.06.2006).

The person authorized to compile the technical file is the Head of Research and Development Department at PRONAR Sp. z o.o., 17-210 Narew, ul. Mickiewicza 101A, Poland.

This declaration relates exclusively to the machinery in the state in which it was placed on the market, and excludes components which are added and/or operations carried out subsequently by the final user.

Narew, the 2018-12-06

Place and date

Z-CIA DYPLEKTOIA
d/s technicznych
członek zarządu
Roman Ochotnicki

*Full name of the empowered person
position, signature*

TABLE OF CONTENTS

1	BASIC INFORMATION	1.1
1.1	IDENTIFICATION	1.2
1.2	INTENDED USE	1.3
1.3	EQUIPMENT	1.5
1.4	TERMS & CONDITIONS OF WARRANTY	1.5
1.5	TRANSPORT	1.6
1.6	ENVIRONMENTAL RISK	1.9
1.7	WITHDRAWAL FROM USE	1.9
2	SAFETY ADVICE	2.1
2.1	BASIC SAFETY RULES	2.2
2.1.1	MACHINE USE	2.2
2.1.2	HITCHING AND UNHITCHING THE MACHINE	2.3
2.1.3	HYDRAULIC SYSTEM	2.4
2.1.4	TRANSPORTING THE MACHINE	2.5
2.1.5	MAINTENANCE	2.5
2.1.6	OPERATING THE MULTIFUNCTION ARM	2.7
2.1.7	OPERATION OF PTO SHAFT	2.8
2.2	RESIDUAL RISK	2.9
2.3	INFORMATION AND WARNING DECALS	2.10
3	DESIGN AND OPERATION	3.1
3.1	TECHNICAL SPECIFICATION	3.2
3.2	DESIGN AND OPERATION	3.5

4	CORRECT USE	4.1
4.1	GET READY FOR OPERATION	4.2
4.2	HITCHING THE MULTIFUNCTION ARM TO THE CARRIER VEHICLE (TRACTOR)	4.4
4.3	BALLASTING THE CARRIER VEHICLE (TRACTOR)	4.10
4.4	START AND OPERATION OF THE MULTIFUNCTION ARM BY MEANS OF THE CONTROL SYSTEM	4.13
4.4.1	CONTROLLING WWT600 MULTIFUNCTION ARM	4.13
4.4.2	CONTROLLING WWT604D MULTIFUNCTION ARM	4.15
4.5	ATTACHING THE WORKING HEAD	4.18
4.6	TRANSPORTING THE MACHINE	4.21
4.7	SETTING THE MULTIFUNCTION ARM IN WORKING POSITION AND OPERATION	4.23
5	MAINTENANCE	5.1
5.1	TECHNICAL INSPECTION	5.2
5.2	HYDRAULIC SYSTEM MAINTENANCE	5.3
5.2.1	OIL TANK AND OIL FILTERS	5.4
5.2.2	MULTIPLIER GEAR BOX WITH THE HYDRAULIC OIL PUMP ASSEMBLY	5.7
5.2.3	HYDRAULIC SELECTIVE CONTROL VALVES (WWT600) AND ELECTROHYDRAULIC SELECTIVE CONTROL VALVES (WWT604D)	5.8
5.3	ELECTRICAL SYSTEM MAINTENANCE	5.10
5.4	LUBRICATION	5.11
5.5	TIGHTENING BOLT CONNECTIONS	5.13
5.6	STORAGE	5.14
5.7	TROUBLESHOOTING	5.15

SECTION

1

BASIC INFORMATION

1.1 IDENTIFICATION




FIGURE 1.1 Location of the nameplate.

PRONAR WWT600 / WWT604D multifunction arms are marked with rating plates located on the lower part of the multifunction arm's frame (FIGURE 1.1). When purchasing the machine, make sure that the serial numbers on the machine are the same as entered in the *WARRANTY BOOK*, in sales documents and in the *OPERATOR MANUAL*.

The meaning of individual items of the nameplate – figure (FIGURE 1.1) are presented in the table below:

A - machine name,	B - machine type/symbol
C – serial number,	D – year of manufacture,
E – gross weight [kg],	F - Quality Control stamp,
G – machine name, name extension	

1.2 INTENDED USE

PRONAR WWT600 / WWT604D multifunction arm is designed and constructed according to current safety and engineering standards.

PRONAR WWT600 / WWT604D multifunction arms are designed to work with working head adjusted to such a type of arm.

The multifunction arm with a working head is designed for the maintenance of municipal infrastructure, urban greenery, orchards and wooded areas and for agricultural works. It could be used for maintaining grass and hedges, trimming branches and boughs, cleaning field drains and for maintaining road infrastructure. Exact intended purpose of the multifunction arm-working head set is described in the Operator Manual of a given working head. The multifunction arm's jointed design and its far reach enables the operator to carry out works in hard-to-access places such as roadside ditches behind safety barriers, slopes and field drains.

Transporting people, animals or other materials is prohibited and regarded as contrary to the intended purpose. During the use of the machine comply with all road traffic regulations and transport regulations in force in the given country, and any breach of these regulations is regarded by the Manufacturer as use contrary to the intended use of the machine.

IMPORTANT



The implement must not be used for purposes other than those for which it is intended, in particular:

- for transporting people and animals,
- for transporting whatever materials or objects.

Using it as intended involves all actions connected with the safe and proper operation and maintenance of the machine. Due to the above, the user is obliged to:

- carefully read the *OPERATOR MANUAL* and comply with its recommendations,
- understand the machine's operating principle and how to operate it safely and correctly,
- adhere to the established maintenance and adjustment plans,
- comply with general safety regulations while working,
- prevent accidents,
- comply with the road traffic regulations and transport regulations in force in the given country, in which the machine is used,
- carefully read the carrier vehicle's Operator Manual and comply with its recommendations.

TABLE 1.1 Requirements for carrier vehicle (agricultural tractor).

CONTENTS	UNIT	REQUIREMENTS
Carrier vehicle's (tractor's) three-point linkage		Rear three-point linkage of Category II according to ISO 730-1 standard
Rear power take-off shaft (PTO)		
Type	-	Type 1 (1 3/8") acc. to ISO 730-1
Rotation speed	rpm	540
Number of splines on PTO shaft	pc.	6
Rotation direction	-	clockwise
Electric sockets		
	–	3-pin socket, 12V (power supply of cooler fan)
	–	7-pin socket, 12V (power supply for rear lamp assembly)
Other requirements		
Minimum carrier vehicle's weight	kg	4500

The multifunction arm may only be used by persons, who:

- are familiar with this publication and the operating instructions of the implement carrier,
- have been trained in the multifunction arm safe operation,
- have the required authorisation to drive and are familiar with the road traffic regulations and transport regulations.

1.3 EQUIPMENT

TABLE 1.2 Equipment of multifunction arm PRONAR WWT600 / WWT604D

EQUIPMENT	STANDARD	OPTION
Operator Manual	•	
Warranty Book	•	
Drive shaft 5R 502 4 BA 502		•
Working head connection TYPE 60		•
Wiring harness of the carrier vehicle (tractor) supplying the cooler fan		•

1.4 TERMS & CONDITIONS OF WARRANTY

PRONAR Sp. z o.o. Narew guarantees the reliable operation of the machine when it is used according to its intended purpose as described in the *OPERATOR MANUAL*. Defects discovered during the warranty period will be removed by the Warranty Service. The repair period is specified in the *WARRANTY BOOK*.

The warranty does not cover those parts and sub-assemblies of the machine which are subject to wear in normal usage conditions, regardless of the warranty period.

The warranty service only applies to such cases as: mechanical damage which is not the user's fault, factory defects of parts, etc.

In the event of damage arising from:

- mechanical damage which is the user's fault, damage caused by road accidents,
- incorrect use, adjustment or maintenance, use of the machine for purposes other than those for which it is intended,
- use of damaged machine,
- repairs carried out by unauthorised persons, repairs carried out improperly,
- making unauthorised alterations to machine design,

the user will lose the right to warranty service.

**TIP**

Demand that the seller carefully and accurately fills out the Warranty Book and warranty repair coupons. A missing date of purchase or sale point stamp may make the user ineligible for any warranty repair or refund.

The user is obliged to report immediately on noticing any wear in the paint coating or traces of corrosion, and to have the faults rectified whether they are covered by the warranty or not. For detailed Terms & Conditions of Warranty, please refer to the WARRANTY BOOK attached to each newly purchased machine.

Do NOT attempt to modify the multifunction arm without the written consent of the Manufacturer. In particular, do NOT weld, drill holes in, cut or heat the main structural elements of the machine, which have a direct impact on the machine operation safety.

1.5 TRANSPORT

The multifunction arm is ready for sale completely assembled and does not require packing. Packing is only required for the machine's technical documentation and any extra accessories.

**IMPORTANT**

When transporting the machine independently, the user must carefully read this Operator Manual and observe all its instructions. When being transported on a motor vehicle the multifunction arm must be mounted on the vehicle's platform in accordance with the transport safety requirements. The driver of the vehicle should use extreme caution while driving. This is due to the vehicle's centre of gravity shifting upwards when the machine is loaded.

Delivery is either by transport on a vehicle or independently. Transport of the machine is permissible connected to a carrier vehicle provided the vehicle's driver familiarises himself with the multifunction arm's Operator Manual and particularly with information concerning safety and principles of hitching and transport on public roads. Do NOT drive the vehicle with the multifunction arm hitched when visibility is limited.

When loading and unloading the multifunction arm, follow the general health and safety regulations for reloading work. Persons operating reloading equipment must have the qualifications required to operate these machines.

**IMPORTANT**

Do NOT secure lifting slings or any types of securing elements to hydraulic cylinders.

**TIP**

During loading, the multifunction arm should be placed in transport position, without the working head. (FIGURE 4.6).




FIGURE 1.2 Support feet of multifunction arm during loading.

(1)- support feet.

During loading and transportation the multifunction arm should stand on support feet (1) (FIGURE 1.2) extended and locked on both sides of the arm at the same height.

The multifunction arm should be firmly secured on the transport vehicle platform with belts or chains equipped with a tensioning mechanism. The fastening equipment used must have a valid safety certificate. Exercise due caution when lifting the machine. During reloading work, special care should be taken not to damage the paint coating.

**IMPORTANT**

Persons must NOT be present in the manoeuvring zone when transferring the multifunction arm to another means of transport.




FIGURE 1.3 Location of centre of gravity of the multifunction arm in transport position (without hydraulic oil in the tank).

TABLE 1.3 Centre of gravity.

Dimension (FIGURE 1.3)	Unit	WWT600 / WWT604D
A	mm	433
B	mm	845
C	mm	1049

1.6 ENVIRONMENTAL RISK

A hydraulic oil leak constitutes a direct threat to the natural environment owing to its limited biodegradability. While carrying out maintenance and repair work which involves the risk of an oil leak, this work should take place on an oil resistant floor or surface. In the event of oil leaking into the environment, first of all contain the source of the leak, and then collect the leaked oil using available means. Remaining oil should be collected using sorbents, or by mixing the oil with sand, sawdust or other absorbent materials. The oil contaminations, once gathered up, should be kept in a sealed, marked, hydrocarbon resistant container, and then passed on to the appropriate oil waste recycling centre. The container should be kept away from heat sources, flammable materials and food.

Oil which has been used up or is unsuitable for further use owing to loss of its properties should be stored in its original packaging in the conditions described above.

1.7 WITHDRAWAL FROM USE

Should you decide to withdraw the machine from use, comply with the regulations in force in the given country regarding withdrawal from use and recycling of machines withdrawn from use.

Before proceeding to dismantle equipment, oil shall be completely removed from hydraulic system and transmission. Locations of drain plugs and method for draining oil are described in Section 5.

When spare parts are changed, worn out or damaged parts should be taken to a collection point for recyclable raw materials. Used oil and also rubber and plastic elements should be taken to the appropriate facilities dealing with the recycling of this type of waste.



IMPORTANT

During dismantling, use the appropriate tools, equipment and use personal protection equipment, i.e. protective clothing, footwear, gloves and eye protection etc.

Avoid contact of skin with oil. Do not allow used oil to spill.

SECTION

2

SAFETY ADVICE

2.1 BASIC SAFETY RULES

2.1.1 MACHINE USE

- Before use, the user must carefully read this Operator Manual and the *WARRANTY BOOK*. When operating the machine, follow all instructions in these documents.
- The multifunction arm may only be used by persons qualified to drive carrier vehicles (tractors) and trained in machine operation. The multifunction arm can be operated by a single person only.
- If the information in this Operator Manual is difficult to understand, contact the seller who runs the authorised technical service on behalf of the Manufacturer, or contact the Manufacturer directly.
- Careless and improper use and operation of the machine, and failure to comply with the instructions of this operator manual is dangerous to your health.
- Be aware of the residual risk. Use caution when operating this multifunction arm and follow all relevant safety instructions.
- The machine must never be used by persons, who are not authorised to drive carrier vehicles (agricultural tractors), including children and people under the influence of alcohol or other drugs.
- Non-compliance with the safety rules of this Operator's Manual can be dangerous to the health and life of the operator and others.
- The machine must not be used for purposes other than those for which it is intended. Anyone who uses the multifunction arm other than the way intended takes full responsibility for himself for any consequences of this use. Use of the machine for purposes other than those for which it is intended by the Manufacturer may invalidate the guarantee.
- The multifunction arm may only be used when all the safety guards and other protective elements are technically sound and correctly positioned. In the event of loss or damage to the protective guards , they must be replaced with new ones.
- Do NOT operate the multifunction arm with the carrier vehicle (tractor) without the driver's cab. The carrier vehicle (tractor) should be equipped with the cab protecting the operator against possible hazards. The operator should also use

personal protective equipment such as protective clothing, safety goggles, safety helmet to reduce the risk of injuries.

- In order to limit occupational risks associated with exposure to noise during multifunction arm operation use individual protection (hearing protectors). In order to reduce the level of noise during work, the operator cab windows and door should be closed.

2.1.2 HITCHING AND UNHITCHING THE MACHINE

- Do not hitch the multifunction arm to the carrier vehicle (agricultural tractor) when the linkage systems of multifunction arm and carrier vehicle are not compatible.
- Only the rear linkage of the carrier vehicle (agricultural tractor) should be used for hitching the machine with the carrier vehicle (agricultural tractor). After hitching the machine, check the safeguards. Carefully read the Operator Manual of the carrier vehicle (agricultural tractor).
- Use only genuine pins and safeguards to hitch the machine to the carrier vehicle (agricultural tractor)
- The carrier vehicle (agricultural tractor) to which the the multifunction arm will be hitched must be technically reliable and must meet the relevant Manufacturer requirements.
- Be especially careful when hitching the machine to the tractor.
- When hitching, there must be nobody between the multifunction arm and the carrier vehicle (agricultural tractor).
- Unhitching the multifunction arm from the carrier vehicle (agricultural tractor) is prohibited when the working head is raised. Exercise caution when unhitching the machine.
- Coupling and uncoupling may only take place when the machine and tractor (carrying vehicle) are turned off.
- Unhitched multifunction arm must be secured against overturning and supported on stable and level surface.

2.1.3 HYDRAULIC SYSTEM

- The hydraulic system is under high pressure when operating.
- Regularly check the technical condition of the hydraulic lines and connections. There must be no oil leaks.
- In the event of the hydraulic system malfunction, discontinue using the machine until the malfunction is corrected.
- When connecting the hydraulic lines to the working head, make sure that the hydraulic system of the multifunction arm is not under pressure. If necessary, reduce residual pressure in the system.
- In the event of injuries being caused by pressurised hydraulic oil, contact a doctor immediately. Hydraulic oil may penetrate the skin and cause infections. In the event of contact of oil with eye, rinse with large quantity of water and in the event of the occurrence of irritation consult a doctor. In the event of contact of oil with skin wash the area of contact with water and soap. Do NOT apply organic solvents (petrol, kerosene).
- Use the hydraulic oil recommended by the Manufacturer. Never mix two types of oil.
- After changing the hydraulic oil, the used oil should be properly disposed of. Used oil or deteriorated oil should be stored in original containers or replacement containers resistant to hydrocarbons. Replacement containers must be clearly marked and appropriately stored.
- Do not store hydraulic oil in packaging designed for storing food or foodstuffs.
- Rubber hydraulic lines must be replaced every 4 years regardless of their technical condition.
- Repair and replacement of hydraulic system elements should be entrusted to the appropriately qualified persons.

2.1.4 TRANSPORTING THE MACHINE

- When driving on public roads, observe all road traffic regulations in force in the country, in which the machine is used.
- Do not exceed the maximum speed resulting from road conditions and design restrictions. Adjust speed to the prevailing road conditions and other limitations arising from road traffic regulations.
- Before beginning travel, the multifunction arm must be folded to transport position.
- Do NOT leave working head raised and unsecured while the carrier vehicle (agricultural tractor) is parked. When parked, the working head should be lowered.
- Do not transport the multifunction arm set in the working position.
- The multifunction arm may not be used or transported in conditions of limited visibility.
- Do NOT ride on the machine or transport any materials on it.
- Before using the machine always check its technical condition, especially in terms of safety. In particular, check the technical condition of the hitch system and elements connecting the hydraulic system.
- Reckless driving and excessive speed may cause accidents.

2.1.5 MAINTENANCE

- During the warranty period, any repairs may only be carried out by warranty service authorised by the Manufacturer. It is recommended that necessary repairs to machine should be undertaken by specialised workshops.
- In the event of any fault or damage, do not use the multifunction arm until the fault has been corrected.
- During work, use appropriate, close-fitting protective clothing, gloves and appropriate tools. When working on hydraulic system it is recommended to use oil resistant gloves and protective goggles.
- Any modification of the multifunction arm releases the manufacturer (PRONAR Narew) from any responsibility for damage or detriment to health which may arise as a result.

- Before commencing any work on the multifunction arm, turn off the carrier vehicle (agricultural tractor) engine and wait until all rotating parts have come to a stop.
- Regularly check the technical condition of the safety devices and correct tightening of bolt connections.
- Regularly perform service inspections of machine as recommended by the Manufacturer.
- Do NOT perform maintenance or repair work under raised and unsupported machine.
- Before beginning repairs on hydraulic systems, reduce oil pressure.
- Servicing and repair work should be carried out in line with the general principles of workplace health and safety. In the event of injury, the wound must be immediately cleaned and disinfected. In the event of more serious injuries, seek a doctor's advice.
- Repair, maintenance and cleaning work should be carried out with the carrier vehicle (agricultural tractor) engine turned off and the ignition key removed. Immobilise the carrier vehicle (agricultural tractor) with parking brake. Ensure that unauthorised persons do not have access to the carrier vehicle (agricultural tractor) cab.
- Should it be necessary to change individual parts, use only original parts. Non-adherence to these requirements may put the user and other people's health and life at risk, and also damage the machine and invalidate the warranty.
- Regularly check technical condition and mounting of all guards and protective elements.
- In the event of work requiring the multifunction arm to be raised, use properly certified hydraulic or mechanical lift jacks for this purpose. After lifting the machine, stable and durable supports must also be used. Do NOT carry out work under a machine, which has been raised only with the three point linkage.
- The machine must not be supported using fragile elements (bricks or concrete blocks).
- After completing work associated with lubrication, remove excess oil or grease.
- In order to reduce the danger of fire the machine must be kept in a clean condition.

2.1.6 OPERATING THE MULTIFUNCTION ARM

- Before starting the multifunction arm, make sure that there are no bystanders (especially children) or animals in the danger zone. The machine operator is obliged to ensure proper visibility of the machine and the working area.
- Before starting the working head drive, lower the working head to working position.
- Multifunction arm operation should begin after reaching nominal PTO speed of 540 rpm. Do NOT overload the multifunction arm's hydraulic system and also do NOT engage the PTO suddenly.
- Do NOT leave the carrier vehicle (agricultural tractor) cab, when the machine drive is engaged.
- Do NOT stand within the multifunction arm's working zone.
- Do NOT operate the working head while reversing. Raise the machine while reversing.
- Keep a safe distance from electric power lines during travel with raised multifunction arm.
- All the control panel operations should be performed only from the operator's seat in the carrier vehicle's (agricultural tractor's) cab. Operating the control panel outside the operator's cab is prohibited.
- Do NOT operate the multifunction arm with a carrier vehicle (tractor) which has a complete vehicle kerb weight smaller than 4500 kg.
- Operation and transport of the multifunction arm is allowed only on slopes with the maximum inclination of 7°. However, due to changing location of centre of gravity depending on type of working head, type of carrier vehicle (tractor) and length of multifunction arm, the allowable slope inclination angle may be smaller. That is why the user must exercise particular caution and determine by himself the maximum slope inclination angle for operating the multifunction arm.
- If the full reach of the multifunction arm is to be used, make sure that stability of the carrier vehicle (agricultural tractor) will be maintained.
- While working on slopes, do not raise the working head more than 0,5 m above the ground.

- In the event of a tilt of the carrier vehicle (agricultural tractor) with the multifunction arm, immediately lower the working head to the ground and stop the carrier vehicle (agricultural tractor).

2.1.7 OPERATION OF PTO SHAFT

- While reversing and during turns, the PTO drive must be disengaged.
- The machine may only be connected to the carrier vehicle (tractor) by means of an appropriately selected PTO shaft recommended by the Manufacturer.
- Adjust the length of PTO shaft to compatible carrier vehicle (tractor) according to the Operator Manual of PTO shaft.
- The PTO shaft has markings on the casing, indicating which end of the shaft shall be connected to the carrier vehicle (tractor).
- Never use a damaged PTO shaft, it may cause an accident. A damaged shaft must be repaired or replaced.
- Disconnect the shaft drive each time when it is not necessary to drive the machine, or when the carrier vehicle (tractor) and the machine are positioned at an unsuitable angle with regard to each other.
- The chains preventing the shaft cover from turning while the shaft is working, shall be secured to a fixed element of machine structure.
- Do NOT use the securing chains to support the shaft while machine is parked or when transporting the machine.
- Before using the machine, carefully read the PTO shaft Operator Manual and follow all instructions.
- The drive shaft must be equipped with a cover. Do NOT use the shaft with damaged or missing guards.
- After connecting the shaft, ensure that it is correctly and safely connected to the carrier vehicle (tractor) and to the machine.
- Before starting PTO shaft, make certain that the PTO rotation direction is correct.
- Before disconnecting the shaft, turn off the engine of the carrier vehicle (tractor) and remove the key from the ignition.
- Do NOT wear loose clothing, straps or whatever that may become wrapped round the rotating drive shaft. Contact with rotating PTO shaft may cause severe injuries.
- Do NOT go over and under the shaft or stand on it equally during work as also when the machine is parked.

2.2 RESIDUAL RISK

Pronar Sp. z o. o. in Narew has made every effort to eliminate the risk of accidents. There is, however, a certain residual risk, which could lead to an accident, and this is connected mainly with the actions described below:

- using the machine for purposes other than those for which it is intended,
- being between the carrier vehicle (agricultural tractor) and the machine while the engine is running and when the machine is being attached,
- being on the machine while the engine is running,
- operating the multifunction arm with removed or faulty safety guards,
- failure to maintain a safe distance from the danger zone or being within the zones while the machine is operating,
- machine operation by unauthorized persons or persons under the influence of alcohol
- cleaning, maintenance and technical checks when carrier vehicle (agricultural tractor) is connected and engine is running.

The residual risk may be kept to a minimum by following the recommendations below:

- operate the machine in prudent and unhurried manner,
- sensibly apply the remarks and recommendations contained in the Operator Manual,
- carry out repairs and maintenance work in line with operating safety rules,
- repair and maintenance work should be carried out by persons trained to do so,
- use close fitting protective clothing,
- ensure unauthorised persons have no access to the machine, especially children.
- maintain a safe distance from forbidden or dangerous places
- do not climb on the machine when it is operating

2.3 INFORMATION AND WARNING DECALS

The multifunction arm is marked with the information and warning decals specified in Table 2.1. Throughout the machine use, you must ensure that any warning messages and information decals located on the machine are clear and legible. If any are destroyed or damaged, they must be replaced with new. Safety decals are available from your PRONAR dealer or directly from PRONAR customer service. New assemblies, changed during repair, must be labelled once again with the appropriate safety signs. When cleaning the multifunction arm, do not use solvents that can damage the coating of information decals and do not subject them to strong water jets.















FIGURE 2.1 Locations of information and warning decals.

Meaning of decals (TABLE 2.1)

TABLE 2.1 Information and warning decals

ITEM	DECAL	MEANING
1		<p>Before starting work, carefully read the Operator Manual.</p>
2		<p>Before maintenance or repairs, turn off engine and remove key from ignition.</p>
3		<p>Use extreme caution when working near electric power lines. Danger of electric shock.</p>
4		<p>Maximum allowable PTO shaft rotation speed is 540 rpm.</p>
5		<p>Danger of being struck. Do not stay within the reach of the multifunction arm and working head</p>
6		<p>Danger of crushing foot or toes</p>
7		<p>No bystanders may stay in the areas marked in this way when implement is in use. If any work is required in these areas, make sure the carrier vehicle (agricultural tractor) is stationary, and whether the implement is disconnected from the power source.</p>
8		<p>Do not reach into crushing space because elements may move. Danger of crushing hands or fingers</p>

ITEM	DECAL	MEANING
9		Lubrication points
10	<p>PRONAR WWT600</p> <p>or</p> <p>PRONAR WWT604D</p>	Machine type
11	<p>PRONAR WWT600</p> <p>or</p> <p>PRONAR WWT604D</p>	Machine type
12		Decal PRONAR
13		Hydraulic oil classification decal
14	<p>PRONAR WWT600</p> <p>or</p> <p>PRONAR WWT604D</p>	Machine type

SECTION

3

**DESIGN AND
OPERATION**

3.1 TECHNICAL SPECIFICATION

TABLE 3.1 BASIC TECHNICAL DATA

	Unit	WWT600	WWT604D
Dimensions			
Total length in transport setting	m	1.35	
Width in transport setting:	m	1.63	
Height in transport setting:	m	3.56	
Technical specification			
Multifunction arm drive	-	Hydraulic - own power source	
Multifunction arm control	-	Mechanical - pull rods	Electrical ON-OFF
Working pressure of the hydraulic system	bar	215	
Maximum power of the hydraulic system (head+arm control in total)	kW	33/6.5 (39.5)	
Oil tank capacity	l	180	
Head rotating angle	°	205	
Floating position rotating angle	°	90	
Arm safeguard	-	Hydraulic safety device	
Oil cooler	-	Standard	
Rear lamp assembly	-	Standard	
Horizontal reach (measured to centre of attachment)	m	5.17	
Extension boom position relative to the carrier vehicle	-	Right	
Weight without a tool (hydraulic system filled with oil)	kg	970	




FIGURE 3.1 Working reach of the multifunction arm with GK110 head.

(1)- reach of centre of attachment;

TABLE 3.2 WORKING REACH OF THE MULTIFUNCTION ARM (FIGURE 3.1)

	Unit	WWT600 / WWT604D
Horizontal reach (A)	m	6.12
Minimum lateral reach (B)	m	1.07
Reach at 45° (C)	m	4.22
Reach on embankment at 45° (D)	m	6.23
Maximum hedge height (E)	m	4.37
Vertical reach (F)	m	7.32
Width of GK110 head (G)	m	1.10
Height above ground (H)	m	0.40

3.2 DESIGN AND OPERATION




FIGURE 3.2 General design

(1)- frame; (2)- three-point linkage lock; (3)- central connector; (4)- support feet; (5)- drive shaft (option); (6)- multiplier gear box with hydraulic pumps; (7)- hydraulic system; (8)- arm shock absorbing unit; (9)- oil tank; (10)- oil cooler; (11)- control system (WWT600); (12)- main arm; (13)- end arm; (14)- working head connection (TYPE 80); (15)- rotary hanger; (16)- shock absorbing unit of hydraulic safety device; (17)- rear lamp assembly; (18)- control panel with a joystick (WWT604D).

Main elements of the multifunction arm:

- three-point linkage with lock
- working head support system arms

- power transmission system
- hydraulic system with controls.

The multifunction arm design is based on frame (1) to which jointed main arm (12) and end arm (13) are connected through rotary hanger (15). The rotary hanger connected with rotation cylinder (hydraulic safety device) protects the multifunction arm against damage when the working head hits an obstacle and makes it possible to set arms (12) and (13) in transport position. At the end of the arm there is an attachment (14) (TYPE 80) for fixing the working head. Attachment (14) (TYPE 60) (with reduced width of working head handle) is available as an option.

There are three attaching points on the frame, which enables the operator to attach the multifunction arm to the rear linkage of the carrier vehicle (tractor) by means of two bottom links of the carrier vehicle (tractor) and a central link (3). During the operation and transport of the multifunction arm, the carrier vehicle's (agricultural tractor) rear three-point linkage is locked with the three-point linkage lock (2). The three-point linkage lock improves the stability of the carrier vehicle - multifunction arm combination.

The multifunction arm is equipped with an independent hydraulic system (7) driven by the carrier vehicle's (tractor) power take-off shaft (PTO) via a drive shaft (5) and multiplier gear box (6) with pumps supplying two circuits of the hydraulic system. One circuit of the hydraulic system is for positioning the arms and the working head while the other circuit is for driving the working head. Hydraulic pumps draw oil from independent oil tank (9) through oil suction filter and pump it into the two hydraulic circuits. Oil tank (9) is located on the frame on the opposite side of the main arm (12) mount. Thanks to this, the oil tank performs also the function of a counterweight.

The hydraulic system is equipped with a hydraulic oil cooler (10) installed on oil return to tank. The cooler fan is powered by the carrier vehicle's (tractor) electrical system through a wiring harness. The fan is switched on by the relay connected with the thermostat installed near the cooler when the allowed oil temperature in the cooler is exceeded. The cooler fan is switched on when oil temperature exceeds 52°C and switched off when oil is cooled down to a temperature below 42°C.

Main arm (12) and end arm (13) are moved by means of hydraulic cylinders. Hydraulic cylinders enable free manoeuvring of the arms of the multifunction arm to which the working head is attached.

Hydraulic cylinders of WWT600 multifunction arm are controlled by means of a hydraulic selective control valve by the carrier vehicle's (tractor) driver using the controls (11). The selective control valve is controlled mechanically by means of cables connected to the controls levers (11).

Hydraulic cylinders of WWT604D multifunction arm are controlled by means of electrohydraulic selective control valve by the carrier vehicle's (tractor) driver using control panel and joystick (18).




FIGURE 3.3 Hydraulic system of WWT600 multifunction arm - diagram

(1) - oil tank; (2) - coarse oil filter (suction filter); (3) - fine oil filter; (4) – quick couplers; (5) - tandem pump; (6) - main arm cylinder; (7) - end arm cylinder; (8) - rotation cylinder; (9) - working head rotation cylinder; (10) - hydraulic accumulator; (11) - cooler; (12) – hydraulic selective control valve of cylinders of support system arms; (13) - hydraulic selective control valve of hydraulic motor of working head




FIGURE 3.4 Hydraulic system of WWT604D multifunction arm - diagram

(1) - oil tank; (2) - coarse oil filter (suction filter); (3) - fine oil filter; (4) – quick couplers; (5) - tandem pump; (6) - main arm cylinder; (7) - end arm cylinder; (8) - rotation cylinder; (9) - working head rotation cylinder; (10) - hydraulic accumulator; (11) - cooler; (12) – electrohydraulic selective control valve of cylinders of support system arms; (13) - electrohydraulic selective control valve of hydraulic motor of working head

SECTION

4

CORRECT USE

4.1 GET READY FOR OPERATION

The manufacturer guarantees that the machine is fully operational and has been checked according to quality control procedures and is ready for use. This does not release the user from an obligation to check the machine's condition after delivery and before first use. The machine is delivered to the user completely assembled.



NOTE

Check technical condition of the multifunction arm before each use. In particular, check the technical condition of the suspension system, hydraulic system, drive system and the integrity of safety guards.

Before hitching to the carrier vehicle (agricultural tractor), the machine operator must check the technical condition of the multifunction arm and prepare it for test start-up. In order to do this:

- the user must carefully read this Operator Manual and observe all recommendations, understand the design and the principle of machine operation,
- check the condition of protective paint coat,
- inspect machine's individual components for mechanical damage resulting from incorrect transport (dents, piercing, bent or broken components),
- check all the lubrication points, lubricate the machine according to recommendations provided in section 5 "MAINTENANCE",



NOTE

Before beginning work lubricate all lubrication points.

- check technical condition of the hydraulic system;
- check if working head, linkage and safety guards are correctly installed,
- check technical condition of hitching system pins and locking cotter pins,
- check the hydraulic oil level in the hydraulic tank and multiplier gear box.

If all the above checks have been performed and there is no doubt as to the machine's good technical condition, it can be hitched to the carrier vehicle (tractor). Start the carrier vehicle's (agricultural tractor`s) engine, check all systems and perform a test run before beginning work. In order to inspect:

- hitch the multifunction arm to the carrier vehicle (tractor) (see "*HITCHING THE MULTIFUNCTION ARM TO THE CARRIER VEHICLE (TRACTOR)*")

- start PTO drive.
- set multifunction arm in working position.

**DANGER**

Do NOT exceed the PTO rotation speed of 540 rpm. Otherwise the multiplier gear box and hydraulic system of the multifunction arm may be damaged.

Engage multifunction arm's drive for 3 minutes and check the following:

- that there is no knocking or noise in the hydraulic pump drive system arising from scraping or grinding of metal elements,
- confirm that there are no oil leaks in the hydraulic system.

The multifunction arm's operation at no load should be smooth. Shaking of drive transmission is not acceptable, nor is abnormal noise and vibrations coming from loose nut and bolt connections. Confirm that oil does not leak from the hydraulic system.

**DANGER**

Before using the multifunction arm, the user must carefully read this Operator Manual. Careless and incorrect use and operation of the multifunction arm, and failure to follow instructions in this Operator Manual is dangerous to your health.

The multifunction arm must never be used by persons, who are not authorised to drive carrier vehicles (agricultural tractors), including children and people under the influence of alcohol or other drugs.

Non-compliance with the safety rules of this Operator's Manual can be dangerous to the health and life of the operator and others.

Before starting the multifunction arm, ensure that there are no bystanders in the danger zone.

If any faults are detected they must be identified and rectified. If a fault cannot be rectified or the repair could void the warranty, please contact retailer for additional clarifications.

4.2 HITCHING THE MULTIFUNCTION ARM TO THE CARRIER VEHICLE (TRACTOR)

PRONAR WWT600 / WWT604D multifunction arm may be hitched to a carrier vehicle (tractor) which meets the requirements specified in Table 1.1 "REQUIREMENTS FOR CARRIER VEHICLE (TRACTOR)".




FIGURE 4.1 Hitching the multifunction arm to the carrier vehicle (tractor).

(A)- lower links of the rear three-point linkage of carrier vehicle (tractor); (B)- upper securing point of the rear three-point linkage of carrier vehicle (tractor); (1)- lower fixing pins of the multifunction arm's linkage; (2)- upper fixing pin of the multifunction arm's linkage; (3)- central connector of the three-point linkage lock system; (4)- lower links of the three-point linkage lock system; (5)- bracket of the three-point linkage lock system; (6)- drive shaft; (7)- locking nut; (8)- pin of the three-point linkage lock; (9)- cotter pin; (10)- washer; (11)- 7-pole electric socket; (12)- 3-pole electric socket; (13)- support feet.



NOTE

Before hitching the multifunction arm to carrier vehicle, read the carrier vehicle (agricultural tractor) Operator Manual. Comply with the recommendations relating to linkage and mounting points.



DANGER

Do NOT operate the multifunction arm with the carrier vehicle (tractor) without the driver's cab. The carrier vehicle (tractor) should be equipped with the cab protecting the operator against possible hazards.

The operator should also use personal protective equipment such as protective clothing, safety goggles, safety helmet to reduce the risk of injuries.



DANGER

When hitching, there must be nobody between the machine and the carrier vehicle (agricultural tractor).

Exercise caution when hitching the machine.



DANGER

Do NOT operate the multifunction arm with a carrier vehicle (tractor) which has a complete vehicle kerb weight smaller than 4500 kg.

In order to hitch the multifunction arm to the carrier vehicle's (tractor) rear three-point linkage, adhere to the following guidelines (FIGURE 4.1):

- Reverse the carrier vehicle (tractor) and bring lower links (A) of the carrier vehicle's (tractor) three-point linkage to lower pins (1) of the multifunction arm and set them at the same height with pins (1).
- Turn off the carrier vehicle's (tractor) engine and immobilize the carrier vehicle (tractor).

- Connect lower links (A) of the carrier vehicle's (tractor) three-point linkage and unlocked lower links (4) of the three-point linkage lock system with two lower pins (1) of the multifunction arm linkage. Secure pins (1) with cotter pins.
- Connect central connector (3) of the three-point linkage lock with the upper fixing point (2) of the multifunction arm linkage.
- Adjust the length of central connector (3) in order to connect the upper securing point of the three-point linkage (B) of carrier vehicle (tractor) with bracket (5) of the three-point linkage lock and secure with a cotter pin;
- Connect the carrier vehicle's (tractor) rear PTO to the multifunction arm's multiplier gear box by means of the drive shaft (6);

Before connecting the multifunction arm to the carrier vehicle's (tractor) PTO shaft, the user must read the Operator Manual supplied by the PTO shaft's manufacturer and follow all instructions. Before connecting the drive shaft, the user shall check the technical condition of guards, the completeness and condition of securing chains and the overall technical condition of the shaft.

**DANGER**

Turn off the carrier vehicle's (tractor) engine and remove the key from the ignition before connecting the carrier vehicle's (tractor) rear PTO with the multifunction arm's multiplier gear box. Ensure that unauthorised persons do not have access to the carrier vehicle (agricultural tractor) cab.

**DANGER**

Before first use, adjust the length of PTO shaft according to Operator Manual of PTO shaft recommendations.

- When links (4) of the three-point linkage lock system are unlocked (FIGURE 4.1), raise the multifunction arm by means of lower links (2) (FIGURE 4.2) of the rear three-point linkage of the carrier vehicle (tractor) to such a height that drive shaft (1) connecting the multifunction arm's multiplier gear box with PTO shaft of the carrier vehicle (tractor) is positioned horizontally with regard to the ground. Both lower links (2) of the rear three-point linkage of the carrier vehicle (tractor) should be positioned at the same height with regard to the ground.




FIGURE 4.2 How to position the multifunction arm in relation to the ground.

(1)- drive shaft; (2)- lower links of the carrier vehicle's (tractor) rear three-point linkage; (3)- central link of the three-point linkage lock system.

- Level the multifunction arm by adjusting the length of central link (3).
- Lock the three-point linkage by fixing the fork of links (4) (FIGURE 4.1) to the bracket of the three-point linkage lock using pins (8). Secure the pins with cotter pins (9). Lock the set length of links (4) of the three-point linkage lock by means of lock nuts (7).



NOTE

Once the carrier vehicle (agricultural tractor) rear three-point linkage is locked with the three-point linkage lock, the user shall not use the control of the carrier vehicle (agricultural tractor) rear three-point linkage. Otherwise the carrier vehicle (tractor) rear three-point linkage and the three-point linkage lock may be damaged.

- Connect 7-pole electric socket (11) (FIGURE 4.1) of the power supply system of rear lamp assembly and 3-pole electric socket (12) of power supply system of the multifunction arm's oil cooler fan and power supply of the control panel (WWT604D)

using connection leads with corresponding electric sockets on the carrier vehicle (tractor).

A 3-pole electric socket installed at the rear of the carrier vehicle (tractor) is required to operate the multifunction arm. If the carrier vehicle is not equipped with such a socket or is equipped with a socket of a different type, install the power supply wiring harness on the carrier vehicle to make it possible to connect the multifunction arm's 3-pin electric socket.



NOTE
Work on electrical system must be carried out by suitably qualified personnel.

- Raise the support feet (10) to the maximum height and secure them with a cotter pin.




FIGURE 4.3 The controls of WWT600 multifunction arm in the carrier vehicle's (agricultural tractor`s) cab with a pictogram.

(A)- controls; (B)- controls pictogram

- Mount the controls (A) (FIGURE 4.3) of WWT600 multifunction arm inside the carrier vehicle's (tractor) cab in the place which makes it possible to manoeuvre the control levers freely from the seat of the carrier vehicle (tractor) operator. The controls should be mounted in a stable manner, without weakening the protective structure of the carrier vehicle (tractor).




FIGURE 4.4 The control panel with joystick of WWT604D multifunction arm in the carrier vehicle's (agricultural tractor's) cab with a pictogram.

(A)- control panel with joystick; (B)- control system pictogram


- Mount the control panel and joystick (A) (FIGURE 4.4) of WWT604D multifunction arm inside the carrier vehicle's (tractor) cab in the place which makes it possible to manoeuvre the controls freely from the seat of the carrier vehicle (tractor) operator. The control panel should be mounted in a stable manner, without weakening the protective structure of the carrier vehicle (tractor). Connect the plug of the control panel's wiring harness (A) (FIGURE 4.4) to the connection socket (4) of the multifunction arm's electrohydraulic system.



NOTE

During operation, the electrical leads should be routed so that they do not get entangled in moving machine and carrier vehicle parts and should be protected against damage during the multifunction arm operation.


4.3 BALLASTING THE CARRIER VEHICLE (TRACTOR)



28-H.04-1

FIGURE 4.5 Ballasting the carrier vehicle (tractor).

Figure description: Table 4.1



NOTE

Misuse of carrier vehicle may cause damage to the vehicle as well as reduce stability, manoeuvrability and braking efficiency of the vehicle.

**NOTE**

Installation of implements on the three-point linkage and a counterweight on the carrier vehicle must not result in exceeding the permissible total weight, permissible axle load and load capacity of carrier vehicle's tyres.

TABLE 4.1 BALLASTING THE CARRIER VEHICLE (DESCRIPTION OF FIGURE 4.5)

SYMBOL / DIMENSION (FIGURE 4.5)	UNIT	DESCRIPTION
T_L	kg	The tare weight of the carrier vehicle
T_V	kg	Front axle load for the carrier vehicle without a machine
T_H	kg	Rear axle load for the carrier vehicle without a machine
t	kg	Load applied to the axles of the carrier vehicle with a machine
t_v	kg	Front axle load for the carrier vehicle with a machine
t_H	kg	Rear axle load for the carrier vehicle with a machine
G_H	kg	Total weight of a rear-mounted machine
G_V	kg	Total weight of a front weight
a	m	Distance between the centre of gravity of the front weight and the front axle centre
b	m	Wheelbase of the carrier vehicle
c	m	Distance between the centre of the rear axle and the centre of the lower linkage arms of the carrier vehicle
d	m	Distance between the centre of the lower linkage arms of the carrier vehicle and the centre of gravity of the rear-mounted machine

Before hitching the machine to the carrier vehicle, confirm that the carrier vehicle is suitable for this purpose. Installation of implements on the rear three-point linkage must not result in exceeding the permissible total weight, permissible axle load and load capacity of carrier vehicle's tyres. The carrier vehicle's front axle must be always loaded with at least 20% of the carrier vehicle's weight.

Make the following calculations (FIGURE 4.5 – I) in order to confirm that these conditions are met:

CALCULATION OF THE MINIMUM FRONT BALLAST G_{Vmin}

$$G_{Vmin} = \frac{G_H \cdot (c + d) - T_V \cdot b + 0.2 \cdot T_L \cdot b}{a + b}$$

CALCULATION OF THE MINIMUM REAR BALLAST G_{Hmin}

$$G_{Hmin} = \frac{G_V \cdot a - T_H \cdot b + 0.45 \cdot T_L \cdot b}{b + c + d}$$

It is assumed that all parameters for the calculations of the minimum front and rear ballast are known.

If the parameters are unknown and cannot be determined, make the measurements using a weighing scale (FIGURE 4.5 – II).

MEASUREMENT OF PERMISSIBLE AXLE LOADS USING A WEIGHING SCALE

- Measure the tare weight of the carrier vehicle (T_L).
- Hitch the machine to the carrier vehicle and measure the front axle load (t_V). If the axle load is smaller than 20% of the carrier vehicle weight (T_L), add weights to exceed the minimum axle load value ($t_V \geq 20\% T_L$).
- Measure the total weight (t) of the carrier vehicle with the machine and weights. Check in the carrier vehicle's Operator Manual if the measured value is smaller than the average value of gross weight.
- Measure the rear axle load (t_H) and check in the carrier vehicle's Operator Manual if the measured value is smaller than the maximum permissible rear axle load of the carrier vehicle (t_{Hmax}).



NOTE

The front axle load of the carrier vehicle must be at least 20% of the carrier vehicle weight.

4.4 START AND OPERATION OF THE MULTIFUNCTION ARM BY MEANS OF THE CONTROL SYSTEM

Once the multifunction arm is attached to the carrier vehicle (agricultural tractor), you may start the machine.



DANGER

The multifunction arm may only be started when all its protection guards are installed properly.

Before engaging PTO drive make sure that there are no bystanders, especially children, near the multifunction arm.



NOTE

Before operating the multifunction arm, lubricate all the lubrication points until the lubricant appears between the shaft and the bearing housing.

Engage rear PTO in the carrier vehicle (agricultural tractor) at a suitably low speed and then gradually increase the speed until PTO speed of 540 rpm is reached. When the proper PTO speed is reached, one may commence work with the multifunction arm.



DANGER

Do NOT exceed the PTO rotation speed of 540 rpm. Otherwise the multiplier gear box and hydraulic system of the multifunction arm may be damaged.

4.4.1 CONTROLLING WWT600 MULTIFUNCTION ARM

The arms of the multifunction arm and working head are controlled by means of the controls inside the carrier vehicle (agricultural tractor) (FIGURE 4.3).



NOTE

All the control panel operations should be performed only from the operator's seat in the carrier vehicle's (agricultural tractor's) cab. Operating the control panel outside the operator's cab is prohibited.




FIGURE 4.6 Controlling WWT600 multifunction arm.

(1)- main arm control lever; (2)- end arm control lever; (3)- working head control lever; (4)- lever controlling the rotation of multifunction arm from working position to transport position; (5)- lever controlling the rotation direction of the working head's hydraulic motor; (6)- locking before the change of the rotation direction of the working head's hydraulic motor; (F)- position of the lever controlling the working head in floating position.

The pictogram showing the lever control diagram is located on the control panel (FIGURE 4.3). Individual functions of control lever (FIGURE 4.6):

- tilt control lever (1) forward or backward to actuate the hydraulic cylinder which tilts the main arm of the multifunction arm;
- tilt control lever (2) forward or backward to actuate the hydraulic cylinder which tilts the multifunction arm's end arm;
- tilt control lever (3) forward or backward to actuate the hydraulic cylinder which tilts the working head. When lever (3) is moved to position (F), the multifunction arm's working head floating position is enabled;
- tilt control lever (4) forward or backward to actuate the hydraulic cylinder which rotates the arms around the axis of rotary hanger;
- tilt control lever (5) forward or backward, after changing the position of lock (6), to actuate right or left hand of rotation of the working head's hydraulic motor.

NOTE



A sudden change of the hand of rotation of the working head's hydraulic motor with control lever (5) may damage the hydraulic system. Hand of rotation of the hydraulic motor can be changed only when the rotation of hydraulic motor and working elements of the working head is completely stopped by shifting the lever to neutral position and then, changing the position of lock (6) and shifting lever (5) to the rotation direction change position.

4.4.2 CONTROLLING WWT604D MULTIFUNCTION ARM

The arms of the multifunction arm and the working head are controlled by means of the control panel with joystick inside the carrier vehicle (tractor) (FIGURE. 4.4).

NOTE



All the control panel and joystick operations should be performed only from the operator's seat in the carrier vehicle's (tractor) cab. Operating the control panel and the joystick outside the operator's cab is forbidden.




FIGURE 4.7 Controlling WWT604D multifunction arm.

(1)- joystick lever; (2),(3)- buttons for controlling the working head movements; (4),(5)- buttons for controlling the rotation of the arms of the multifunction arm around the hanger axis; (6)- button for activation of working head's floating function; (7)- switch for activation and changing the rotation direction of the working head drive; (8)- switch for activation of the arm shock absorbing unit; (9)- power supply switch (mushroom button); (10)- indicator light of power supply of control panel; (11)- indicator light of activation of the arm shock absorbing unit; (12)- indicator light of activation of the anti-clockwise rotation of the working head drive; (13)- indicator light of activation of the clockwise rotation of the working head drive; (14)- safety button.

Before manoeuvring the multifunction arm, confirm that the power supply switch of the control panel (9) (FIGURE 4.7) is in the unlocked position. If the switch is depressed and locked, turn

it to unlock. Activation of the power supply of the control panel is signalled by the indicator light (10).

The hydraulic drive of the working head is switched on by depressing the right or left side of the button (7), depending on the selected rotation direction of the working head drive. The working head drive is OFF when the switch is set in its central position. The selected rotation direction of the working head drive is indicated by the indicator lights (12) or (13).

When the arm shock absorbing function is required, turn on switch (8). When ground surface tracking is required for the working head, press button (6) of the working head's floating function.

When immediate emergency stopping of the multifunction arm is required, press the power supply switch of the control panel (mushroom button) (9). This button switches off the complete control system of the multifunction arm.

The multifunction arm movements are controlled by means of the joystick. The pictogram placed on the joystick lever mounting (1) (FIGURE 4.7) shows the joystick control diagram.



NOTE

To control the multifunction arm movements, the operator must hold the joystick and press the safety button simultaneously (14) (FIGURE 4.7). This prevents accidental activation of the multifunction arm hydraulic cylinders when the joystick is unintentionally touched.

Individual functions of the joystick (FIGURE 4.7):

- tilt joystick lever (1) forward or backward to actuate the hydraulic cylinder which tilts the main arm of the multifunction arm;
- tilt joystick lever (1) to the right or left to actuate the hydraulic cylinder which tilts the end arm of the multifunction arm;
- press the right (2) or left (3) function button on the joystick to actuate the hydraulic cylinder which tilts the working head. When the button (6) is depressed, the head tilt floating position function is ON.
- press the right (4) or left (5) function button on the joystick to actuate the hydraulic cylinder which rotates the arms of the multifunction arm around the hanger axis.

4.5 ATTACHING THE WORKING HEAD

WWT600 / WWT604D multifunction arm can be connected with working heads designed for cooperating with the working head connection and hydraulic system of the multifunction arm.



NOTE

Before attaching the working head, the user must carefully read the Operator Manuals of the working head, carrier vehicle (agricultural tractor) and multifunction arm and observe all instructions contained in the manuals.



DANGER

When hitching, there must be nobody between the machine and the carrier vehicle (agricultural tractor).

Exercise caution when hitching the machine.



DANGER

Before attaching the working head, turn off the carrier vehicle's (tractor) engine and remove the key from the ignition. Ensure that unauthorised persons do not have access to the carrier vehicle (agricultural tractor) cab.

Check technical condition of the working head's guards and general technical condition of the machine.




FIGURE 4.8 Attaching the working head to the multifunction arm.

(1)- working head attachment TYPE 80 (option: TYPE 60); (2)- working head attachment holder; (3)- working head attachment lock; (4)- clamping bolts; (5)- nuts; (6)- washers; (7)- connecting bracket; (8) - working head attachment plate; (A)- hydraulic return quick coupler (socket); (B)- hydraulic supply quick coupler (socket); (C)- hydraulic supply quick coupler (plug).

In order to hitch the working head to the multifunction arm head (FIGURE 4.8), proceed as follows:

- Reverse the carrier vehicle (tractor) and bring the multifunction arm's head attachment (1) close to the working head's attachment (support beam) or, depending on the head version, bring the connecting bracket (7) close to the attachment plate (8).
- Using the controls, position the multifunction arm's head attachment (1) at the same height as the working head's attachment (support beam). Manoeuvre the arms to bring the bracket (7) close to the plate (8).

- Turn off the carrier vehicle's (agricultural tractor) engine and prevent the carrier vehicle (tractor) from moving.
- Connect the multifunction arm's head attachment (1) to the working head's attachment (support beam) by means of holder (2) and lock (3) of the attachment. Screw the entire assembly together with four fixing bolts (4). Bolt the multifunction arm's connecting bracket (6) to the attachment plate (7) of the working head.
- Connect the hydraulic quick couplers (A), (B) and (C) of the multifunction arm with the corresponding quick couplers of the working head's hydraulic lines.
- Turn on the carrier vehicle's (agricultural tractor) engine and the multifunction arm's drive. Raise the working head by means of the multifunction arm's controls.

**DANGER**

Prior to connecting individual hydraulic system lines, the user must carefully read the Operator Manual of the multifunction arm and working head and observe all recommendations of the Manufacturer.

**DANGER**

When connecting the hydraulic quick couplers to the working head, make sure that the hydraulic system of the multifunction arm is not under pressure.

4.6 TRANSPORTING THE MACHINE

IMPORTANT



Before driving on public roads in order to transport the multifunction arm to the work site and back, the multifunction arm shall be folded to its transport position.

When driving on public roads, observe all road traffic regulations in force in the country, in which the machine is used.

Before driving onto a public road, check if all the lights and warning plates on the multifunction arm are properly mounted and visible.

The multifunction arm may not be used or transported in conditions of limited visibility.





FIGURE 4.9 Transport position

(1)- main arm, (2)- end arm; (3)- working head connection.

For transport to place of work and back, set the multifunction arm in transport position (FIGURE 4.9) so that the multifunction arm width is minimal and the height measured from the road surface does not exceed the permissible height (4 metres) stipulated by the road traffic regulations.



DANGER

During transport, pay special attention and exercise particular caution when driving the carrier vehicle with the multifunction arm under viaducts, bridges and electric power lines.





FIGURE 4.10 Ball valves in the transport position

(1)- ball valves of arms tilt cylinders, (2)- ball valve of arm shock absorbing unit; (A)- OPEN valve; (B)- CLOSED valve.

After setting the multifunction arm in transport position, switch the ball valves protecting cylinders (1) and arm shock absorbing unit (2) to CLOSED position (B) (FIGURE 4.10). In the case of WWT604D multifunction arm, set the switch (8) (FIGURE 4.7) of the arm shock absorbing unit to OFF position.



DANGER

The drive of the working head shall not be turned on when the multifunction arm is in its transport position.

4.7 SETTING THE MULTIFUNCTION ARM IN WORKING POSITION AND OPERATION

To set the multifunction arms in working position:

- switch the ball valves (1) of cylinders to the OPEN position (A) (FIGURE 4.10);
- turn on the drive of the carrier vehicle's (agricultural tractor) rear PTO;
- operate appropriate hydraulic cylinders of the multifunction arm (FIGURE 4.6) (WWT600) or (FIGURE 4.7) (WWT604D) in order to place the working head in the working area (FIGURE 4.11);




FIGURE 4.11 Examples of working positions of the multifunction arm with GK110 cutting head.

- turn on the hydraulic motor which drives the working head using the multifunction arm's controls (FIGURE 4.6) (WWT600) or (FIGURE 4.7) (WWT604D);

DANGER



The working head may only be started when all the protection guards of the multifunction arm and working head mounted properly and the working head is in its working position.

Bystanders should be at a safe distance from the multifunction arm's working head during work because of the risk of injury caused by thrown objects (stones, branches etc.).

- engage appropriate carrier vehicle (agricultural tractor) gear and start working.

During operation, the multifunction arm operator must ensure proper visibility of the machine and work area so that the operator can see obstacles and possible dangers in the route of the working head. The rotating elements of the working head shall never be directed towards the carrier vehicle (agricultural tractor (FIGURE 4.12)).




FIGURE 4.12 Safe position of the working head during hedge trimming.

**DANGER**

NEVER work if the rotating elements of the working head are directed towards the carrier vehicle (agricultural tractor). Otherwise the carrier vehicle (agricultural tractor) may be damaged or the operator may be injured.

**DANGER**

During operation with the arm of the multifunction arm raised, keep the arms and working head at a safe distance from overhead power lines (FIGURE 4.13).




FIGURE 4.13 Safe distances of the machine from power lines.

In line with regulations in force, it is not acceptable to place work stations, machines or devices directly below overhead power lines or at a distance, calculated horizontally from extreme lines, lower than (FIGURE 4.13):

- 3 m - for lines with rated voltage up to 1 kV,
- 5 m - for lines with rated voltage above 1 kV and up to 15 kV,
- 10 m - for lines with rated voltage above 15 kV and up to 30 kV,
- 15 m - for lines with rated voltage above 30 kV and up to 110 kV,
- 30 m - for lines with rated voltage above 110 kV.

If it is impossible to keep the minimum distances in order to work safely in the vicinity of power lines, then apply to the nearest Power Utility and have the lines deenergised for the duration of operation.

NOTE

Operation and transport of the carrier vehicle (agricultural tractor) with hitched multifunction arm is allowed only on slopes with the maximum inclination of 7°. However, due to changing location of centre of gravity depending on type of working head, type of carrier vehicle (agricultural tractor) and length of multifunction arm, the allowable slope inclination angle may be smaller. That is why the user must exercise due caution and determine the maximum slope inclination angle for operating the carrier vehicle (agricultural tractor) with the multifunction arm.



If the full reach of the multifunction arm is to be used, make sure that stability of the carrier vehicle (agricultural tractor) will be maintained.

While working on slopes, do not raise the working head more than 0,5 m above the ground.

In the event of a tilt of the carrier vehicle (agricultural tractor) with the multifunction arm, immediately lower the working head to the ground and stop the carrier vehicle (agricultural tractor).




FIGURE 4.14 WWT600 arm shock absorbing unit.

(1)- ball valve of arm shock absorbing unit, (A)- OPEN valve; (B)- CLOSED valve.

When the working head moves along an uneven ground and requires frequent changes of its titling position, enable the floating position function for the titling of the working head by moving control lever (3) to position (F) (FIGURE 4.6) (WWT600) or pressing button (6)

(FIGURE 4.7) (WWT604D). At the time, the head changes its tilting position smoothly and adjusts its setting to the ground irregularity (D) (FIGURE 4.15).




FIGURE 4.15 Arm shock absorbing function and head tilt floating position function.

(A)- operation of the working head with the arm shock absorbing function disabled; (B)- operation of the working head with the arm shock absorbing function enabled; (C)- operation of the working head with the head tilt floating position function disabled; (D)- operation of the working head with the head tilt floating position function enabled.

When the working head is operated at the ground level and requires the function of tracking the ground surface along which it moves in the vertical plane, enable the arm shock absorbing function by opening (A) valve (1) of the arm shock absorbing unit (FIGURE 4.14) (WWT600) or turning on the switch (8) (FIGURE 4.7) (WWT604D). At the time, the arm of the multifunction arm changes its vertical position smoothly and adjusts the head's setting to the ground irregularities (B) (FIGURE 4.15).

When the working head is being operated with the arm of the multifunction arm raised, disable the working head's tilt floating position and the arm shock absorbing function.

When the multifunction arm with working head is raised, always start operating the working head at the highest point and move the head gradually downward. When the operation of the working head involves the falling of diverse plant material (branches) from a height, secure the work site so that no one is present in the zone of operation of the head and of the falling plant material.

**DANGER**

Bystanders should be at a safe distance from the multifunction arm's working head during operation with the arm raised because of the risk of diverse material (stones, branches etc.) falling and being thrown by the head.

While operating the multifunction arm, pay attention to uneven surface and obstacles on the route of moving multifunction arm. When an obstacle is encountered, the main arm will rotate on rotary hanger (15) (FIGURE 3.2). In such a case, stop the carrier vehicle as quickly as possible and bypass the obstacle with the working head raised.

When driving across the road, pavement or other obstacles and when making turns, raise the working head and disengage the working head drive.

Be especially careful when mowing along ditches, furrows and slopes. If overheating of the multifunction arm hydraulic system occurs during operation of the working head, disengage the PTO drive and find the cause of overload.

While operating the multifunction arm, adjust the carrier vehicle's (agricultural tractor) speed. The speed depends on a number of factors. The main ones are:

- the working head type used
- the type of the material along which the working head moves
- the type and configuration of the ground along which the carrier vehicle travels
- weather conditions.

In all those cases, use the lowest possible speed of the carrier vehicle (agricultural tractor) at constant revolutions of the engine so that the carrier vehicle's PTO revolutions were fixed and equal to 540 rpm.

**HIGH NOISE LEVEL WARNING**

Depending on the working conditions, the carrier vehicle (agricultural tractor) with the machine may generate noise exceeding the level of 85dB at the driver position. In such conditions, the operator should use personal protective equipment (ear protectors).

In order to reduce the level of noise during work, the operator cab windows and door should be closed.




FIGURE 4.16 Throttle-check valves of arm tilt cylinders.

(1)- throttle-check valve of main arm tilt, (2)- throttle-check valve of end arm tilt; (A)- reduction of oil flow speed; (B)- increase of oil flow speed.

Hydraulic system supplying arm tilt hydraulic cylinders is equipped with throttle-check valves for adjusting oil flow speed (FIGURE 4.16). Consequently, working speed of arm tilt cylinders can be adapted to individual needs of multifunction arm operator.

The valve is regulated by turning it.

Turn the valve to the right, in the direction of oil flow, in order to reduce the flow speed. Reduction of oil flow speed slows down the cylinder motion and improves smoothness of its operation.

Turn the valve to the left, in the direction of oil flow, in order to increase the flow speed. Increase of oil flow speed accelerates the cylinder motion and reduces smoothness of its operation.




FIGURE 4.17 Method of increasing the maximum reach of the main arm of the multifunction arm.

(1)- main arm cylinder rod, (2)- cylinder pin; (3)- securing pin; (A)- location of cylinder pin for the maximum vertical reach of the arm; (B)- location of cylinder pin for the maximum horizontal reach of the arm.

Arms of hydraulic multifunction arm can achieve the maximum vertical or horizontal reach (FIGURE 4.17).

To achieve the maximum vertical reach of the working head on the multifunction arm with regard to the ground, place the eye of the main arm cylinder rod (1) on pin (2) located in hole (A) and secure with securing pin (3).

To achieve the maximum horizontal reach of the working head on the multifunction arm with regard to the ground, place the eye of the main arm cylinder rod (1) on pin (2) located in hole (B) and secure with securing pin (3).

	<p>IMPORTANT</p>
<p>Position of the eye of the main arm cylinder rod may be changed only if the multifunction arm is lowered and supported on support feet and the main arm is secured against falling. Set the arms of the multifunction arm in such a manner as to ensure that the working head installed on the arm rests on the ground.</p>	

SECTION

5


MAINTENANCE

5.1 TECHNICAL INSPECTION

To get the multifunction arm ready for use, check components according to guidelines presented in Table 5.1.

TABLE 5.1 TECHNICAL INSPECTION SCHEDULE

DESCRIPTION	MAINTENANCE ACTIVITIES	FREQUENCY
Correct mounting of the multifunction arm on the carrier vehicle's (tractor`s) linkage	Check if correctly installed	Daily before beginning work
Technical condition of the multifunction arm's hydraulic system	Check according to section „5.2 <i>HYDRAULIC SYSTEM MAINTENANCE</i> ”	
The oil level in the hydraulic oil tank and multiplier gear box	Check according to section „5.2 <i>HYDRAULIC SYSTEM MAINTENANCE</i> ”	
Check if all main nut and bolt connections are properly tightened	Tightening torque should be according to table 5.3	
Lubrication	Lubricate the components according to section „5.4 <i>LUBRICATION</i> ”.	
Replace oil filter	According to section "5.2.1 OIL TANK AND OIL FILTERS"	Oil filter: After the first 100 h, then every 500 h or once a year Oil suction filter: Every 1000 h or once a year
Change oil in tank	According to section "5.2.1 OIL TANK AND OIL FILTERS"	Every 1000 h or once a year
Change oil in multiplier gear box	According to section "5.2.2 MULTIPLIER GEAR BOX WITH HYDRAULIC OIL PUMP ASSEMBLY"	After the first 50 h, then every 1000 h or every 6 months

	<p>NOTE</p> <p>Do NOT use out of order multifunction arm.</p>
---	--

5.2 HYDRAULIC SYSTEM MAINTENANCE



DANGER

Before commencing whatever work on hydraulic system reduce the pressure in the system.



DANGER

During work on hydraulic system, use the appropriate personal protection equipment i.e. protective clothing, footwear, gloves and eye protection. Avoid contact of skin with oil.

Make sure that the oil in the multifunction arm hydraulic system is of adequate grade. Do not add hydraulic oil of other grade. The hydraulic system in a new multifunction arm is filled with HL46 hydraulic oil.



NOTE

The condition of hydraulic system should be inspected regularly while using the machine.

Flexible hydraulic lines should not be entwined or fractured.

The hydraulic system must be tight. Inspect the seals when hydraulic cylinders are completely extended. If oil is found on hydraulic cylinder body, check origin of leak. Minimum leaks are permissible with symptoms of "sweating", however in the event of noticing leaks in the form of "droplets" stop using the machine until faults are remedied.

If an oil leak is found on hydraulic connections, tighten the connections. If this does not remedy the problem, replace the lines and connection components. Always exchange each mechanically damaged component. Also, pay attention to ensure that flexible hydraulic lines are not fractured or entwined.



Flexible hydraulic lines should be replaced every 4 years of the machine operation.

TABLE 5.2 HL46 HYDRAULIC OIL SPECIFICATION

ITEM	NAME	VALUE
1	ISO 3448VG viscosity classification	46
2	Kinematic viscosity at 40°C	41.4 ÷ 50.6 mm ² /s
3	ISO 6743/99 quality classification	HL
4	DIN 51502 quality classification	HL
5	Flash-point	above 220 °C

Because of its composition, the oil is not classified as a dangerous substance, however long-term action on the skin or eyes may cause irritation. In the event of contact of oil with skin wash the place of contact with water and soap. Do NOT apply organic solvents (petrol, kerosene). Contaminated clothing should be changed to prevent access of oil to skin. In the event of contact of oil with eye, rinse with large quantity of water and in the event of the occurrence of irritation consult a doctor. Hydraulic oil in normal conditions is not harmful to the respiratory tract. A hazard only occurs when oil is strongly atomised (oil vapour), or in the case of fire during which toxic compounds may be released. Oil fires should be quenched with carbon dioxide (CO₂), foam or extinguisher steam. Do NOT use water for fire extinguishing.

Spilt oil should be immediately collected and placed in a marked tight container. Used oil should be taken to the appropriate facility dealing with recycling or regeneration of oils.

5.2.1 OIL TANK AND OIL FILTERS

The oil tank (1) (FIGURE 5.1) holds 180 l of hydraulic oil type HL46. Check tank welded joints and hydraulic hoses for leaks every day.




FIGURE 5.1 Oil tank

(1)- oil tank; (2)- oil inlet cap; (3)- oil level indicator; (4)- drain plug, (5)- oil filter; (6)- oil suction filter (inside the oil tank); (7)- tank inlet cover.

Change the oil in the tank after every 1000 hours of operation of the multifunction arm or once a year, whichever occurs first. In order to change oil in the tank, unscrew filler plug (2) and suck off oil from the tank through the inlet opening by means of a pump for sucking oil off. Drain oil remaining on the tank bottom to previously prepared vessel through drain plug (4). Pour fresh oil into the tank through a strainer in the top inlet opening (2) of the tank having previously screwed the drain plug (4) in.

Before pouring oil in, change the suction filter (6) inside the oil tank.



While changing oil in the tank, always change the suction filter (6) inside the tank and the external filter (5).

Replace the suction filter (6) (inside the oil tank) every 1000 hours of operation of the multifunction arm or once a year while changing oil in the tank, whichever occurs first. To this end, unscrew the tank inlet cover (7) and through the opening in the tank unscrew the oil suction filter (6).

The oil filter (5) is located on the oil return to the tank. Replace the filter for the first time after 100 hours of operation of the multifunction arm. Then replace the filter every 500 hours of operation of the multifunction arm or once a year, whichever occurs first. Replace the oil filter (5) also when changing oil in the tank. In order to change filter:

- unscrew the clogged filter housing;
- cover sealing ring of new filter with oil (a few drops);
- screw in new filter until sealing ring and casing make contact and then screw in by hand making one more half turn (do not screw in too tightly).

NOTE



When unscrewing used suction filter (6) or oil filter (5), do not use hammer, chisel etc. as this may damage the filter body. Use filters recommended by the machine manufacturer (original filters).

Screw in filter by hand, without use of any tools.

Each time you change the oil and filters and during the daily checks of the multifunction arm hydraulic system, check the oil level on the tank sight glass (3). Sight glass float indicator should be near the top. If the indicator shows an insufficient oil level, fill the tank with oil to the required level.

5.2.2 MULTIPLIER GEAR BOX WITH THE HYDRAULIC OIL PUMP ASSEMBLY




FIGURE 5.2 Multiplier gear box with hydraulic pump and viscosity classification of gear oils depending on the ambient temperature.

(A)- multiplier gear box; (B)- hydraulic pumps assembly; (1)- oil filler plug; (2)- sight-glass; (3)- drain plug; (4)- air vent.

There must be no oil leaks from the multiplier gear box (A) and pumps (B) (FIGURE 5.2). These can be stopped by tightening the mounting bolts or replacing the seals. If needed, remove the oil filler cap (1) or air vent (4) and add gear oil to sight-glass level (2). To change the oil, unscrew the drain cap (3) and drain the oil into a prepared vessel. Then pour oil into the multiplier gear box through the filler plug (1) or air vent (4) to the level of the sight-glass (2).

NOTE



ISO L-CKC or API GL-3/GL-5 quality grade gear oil may be used. The viscosity grade of the gear oil is selected depending on the ambient temperature (FIGURE 5.2).

As a standard, the multiplier gear box is filled with gear oil of API GL-3 / GL-5 quality grade and SAE 90 viscosity grade.

NOTE



Tighten the G3/8" plugs (drain plug, filler plug, sight-glass and air vent of the multiplier gear box) with 30 Nm (+/- 2 Nm) torque.

5.2.3 HYDRAULIC SELECTIVE CONTROL VALVES (WWT600) AND ELECTROHYDRAULIC SELECTIVE CONTROL VALVES (WWT604D)




FIGURE 5.3 Hydraulic selective control valves (WWT600).

(1)- hydraulic selective control valve for support system arms cylinders; (2)- hydraulic selective control valve for the working head hydraulic motor.




FIGURE 5.4 Electrohydraulic selective control valves (WWT604D).

(1) - electrohydraulic selective control valve of cylinders of support system arms; (2) - electrohydraulic selective control valve of the working head's hydraulic motor.

Hydraulic selective control valve (1) (FIGURE 5.3) or electrohydraulic selective control valve (1) (FIGURE 5.4) is used for controlling four hydraulic cylinders of the support system.

Single-section hydraulic selective control valve (2) (FIGURE 5.3) or electrohydraulic selective control valve (2) (FIGURE 5.4) is used for starting the working head's hydraulic motor. The selective control valves are controlled by means of mechanical control system (WWT600) or electrically by means of control panel with joystick (WWT604D) in the tractor cab. Check the condition of seals of selective control valves daily and pump grease into all grease nipples located on individual sections of hydraulic selective control valves.

NOTE



Each hydraulic or electrohydraulic selective control valve is equipped with overflow valves that are set in the factory by the Manufacturer for proper working pressure of the multifunction arm's hydraulic system.

Do NOT adjust overflow valves because it may lead to damage to the multifunction arm's hydraulic system and working head. Adjustment of overflow valves should be carried out by an authorised service station of the machine manufacturer.

5.3 ELECTRICAL SYSTEM MAINTENANCE



DANGER

Do not independently repair electrical system, except items described in section "ELECTRICAL SYSTEM MAINTENANCE". All electrical system repairs must be performed only by suitably qualified personnel.

Maintenance of electrical system involves checking the operation of power supply system of oil cooler fan and lighting system. In WWT604D multifunction arm, check also the control panel with joystick for correct operation.

The multifunction arm's hydraulic system is equipped with a hydraulic oil cooler on which a fan supplied from the carrier vehicle's (tractor) electrical system is installed. The fan is switched on by the relay connected with the thermostat installed near the cooler when the allowed oil temperature in the cooler is exceeded. The cooler fan is switched on when oil temperature exceeds 52°C and switched off when oil is cooled down to a temperature below 42°C.

Light-emitting diodes (LED) are used as the source of light in lamp assemblies. Thanks to this, the lamps are maintenance-free because there is no need to change bulbs.



IMPORTANT

Before beginning repairs of electrical system, disconnect the machine from power source.



IMPORTANT

Do NOT travel with out of order lighting system. Burned-out or damaged lamps must be replaced with new ones.

5.4 LUBRICATION





FIGURE 5.5 Location of lubrication point pictograms.



When using the machine the user is obliged to observe lubrication instructions according to attached schedule. Excess lubricant causes depositing of additional contaminants in places requiring lubrication, therefore it is essential to keep individual machine components clean.

Grease all grease nipples located on the machine in places marked with the following pictogram (FIGURE 5.5):



Those are all the pins of articulated joints of the support system arms and the lugs of hydraulic cylinders.

Additionally, lubricate the drive shaft (option) in line with the shaft's Operator Manual provided by the drive shaft manufacturer and pump grease into all grease nipples located on individual sections of hydraulic selective control valves (FIGURE 5.3).

Machine lubrication should be performed with the aid of a manually or foot operated grease gun, filled with generally available grease. Before commencing lubrication insofar as is possible remove old grease and other contamination. Remove and wipe off excess oil or grease

5.5 TIGHTENING BOLT CONNECTIONS

Before each use of the machine and during maintenance and repair work, confirm that all bolt connections are properly tightened. If any clearances in bolt connections are found, tighten bolt connections using appropriate tightening torque (TABLE 5.3), unless other tightening parameters are given. Recommended torque values apply to non-greased steel bolts.



NOTE

Should it be necessary to change individual parts, use only original parts or those indicated by the Manufacturer. Non-adherence to these requirements may put the user and other people's health and life at risk, and also cause damage to the machine.

TABLE 5.3 TIGHTENING TORQUE FOR NUT AND BOLT CONNECTIONS

THREAD DIAMETER [mm]	5.8	8.8	10.9
	TIGHTENING TORQUE [Nm]		
M6	8	10	15
M8	18	25	36
M10	37	49	72
M12	64	85	125
M14	100	135	200
M16	160	210	310
M20	300	425	610
M24	530	730	1 050
M27	820	1 150	1 650
M30	1050	1 450	2 100
M32	1050	1 450	2 100

5.6 STORAGE

After finishing work, clean and wash the multifunction arm thoroughly with a water jet. While washing do not direct a strong water or steam jet at information and warning decals, bearings or hydraulic lines. Nozzle of pressure or steam washer should be kept at a distance of not less than 30 cm from cleaned surface.

After cleaning, inspect the whole machine, inspect technical condition of individual elements. Repair or replace any used or damaged components.

In the event of damage to the paint coat, clean rust and dust from damaged area, degrease and then paint with undercoat and after it is dry paint with surface coat paint retaining colour uniformity and even thickness of protective coating. Until the time of touch-up painting, the damaged place may be covered with a thin layer of grease or anticorrosion preparation. Multifunction arm should be kept in a closed or roofed building.

If the multifunction arm will not be used for an extended period of time, protect it against adverse weather conditions. The multifunction arm should be lubricated according to the instructions provided regardless of the date of the last lubrication. Protect against corrosion all cooperating elements i.e. pins, articulated joints, hydraulic cylinder rods. Cover them with a thin layer of grease.

The multifunction arm should be stored in a roofed building inaccessible for children and animals. The multifunction arm disconnected from the carrier vehicle (tractor) should be placed on support feet, on level, sufficiently hard surface in such a manner as to ensure that it is possible to connect it again. Set the arms of the multifunction arm in such a manner as to ensure that the working head installed on the arm rests on the ground. Dismount the control panel of the multifunction arm or the control panel with joystick from the cab of the carrier vehicle (tractor) and protect it against adverse weather conditions.

5.7 TROUBLESHOOTING

TABLE 5.4 TROUBLESHOOTING

TYPE OF FAULT	POSSIBLE CAUSE	REMEDY
It is impossible to control support system arms	The power supply switch of the control panel is depressed (WWT604D)	Unlock the power supply switch of the control panel (turn it)
	Control system or control system cables are damaged (WWT600)	Repair at an authorised service point
	Damaged control panel (joystick) (WWT604D)	Repair at an authorised service point
	Fuse is blown (WWT604D)	Replace the fuse on the power supply wiring harness of the fan
	Multifunction arm's hydraulic system is out of order	Check individual elements of the multifunction arm's hydraulic system
	Selective control valve is damaged	Repair at an authorised service point
Overheating of the multiplier gear box	Wrong level of oil in the multiplier gear box casing	Check oil level.
	Damaged multiplier gear box bearings	Repair at an authorised service point
It is impossible to start the working head or the head is working too slowly	Control system is damaged (WWT600)	Repair at an authorised service point
	Damaged control panel (joystick) (WWT604D)	Repair at an authorised service point
	Fuse is blown (WWT604D)	Replace the fuse on the power supply wiring harness of the fan
	Selective control valve is damaged	Repair at an authorised service point
	Hydraulic pump is damaged	Repair at an authorised service point
	Damaged PTO drive	Check PTO drive
Oil cooler fan does not turn on	Damaged thermostat	Replace the cooler thermostat with a new one
	Fuse is blown	Replace the fuse on the power supply wiring harness of the fan
	Power supply failure of fan electrical system	Check power supply

NOTES

A series of horizontal dotted lines for writing notes.



